

4132 Installation

Step 1 Per to below brass bracket, drill hole on the right place of wall, then screw tightly, to fix bracket.



Step 2 Screw two grub screws to fix roll hold on brass bracket

