

### 3MODGR Instruction

All components as below



Step 1 Use Allen Key to loose grub screw, take out bracket.



Step 2 drill hole on the needed place of wall, Insert rawl plugs into hole, and then turn on screws on rawl plugs to fix bracket .

Step 3 Put holder on the bracket, screw back grub screw tighten.

