

TRHK01 Instructions

<p>2X 2X 2X 1X 2X</p>	<p>1X 1X</p>
<p>Accessories</p>	<p>Required tools</p>

Please read this instructions carefully before assembly

Please be noted that this part is only available for crossbar whose diameter is no less than 22mm

1 Put the hex screw to the part shown above

2 Fasten this part to the other part using allen key and secure them to the radiator

1 Put the bar to the hole of the connector

2 Put the other end of the other connector, don't secure the snap screw

3 Adjust the position of the connector, and assemble it to the part on the radiator

Using M5*8 screw to secure the connector

Using M5*5 screw to secure the bar

Well done !