

# Unipanel Bath Panel Fixing Kit Instructions

Screw the threads into the brackets

Once all the threads have been screwed in, snap the squares onto the end, then stick the velcro stickers to the squares.



**Screw the threads into the brackets**



Place circular pad under bath lip and tighten.

Screw in the threads so the square is tight.



**Place circular pad under bath lip and tighten**



Threads can be cut shorter for narrow bath edges.

If the threads are touching the bath before the square is tight, unscrew them and cut shorter. (easy to cut, as made from plastic.)



**Threads can be cut shorter for narrow bath edges**



Screw in shorter threads

Once you have cut the thread ends shorter, screw them in tight.



**Screw in shortened threads**



Apply opposite velcro pads to the bath panel.

Line up the panel to the threads and apply the opposite velcro squares. Stick to the existing velcro squares and clip the panel into the bath lip.



**Apply opposite velcro pads to the bath panel**

