

FITTING INSTRUCTIONS

Note: The wall plugs supplied are only suitable for solid stone / brick walls. For plasterboard walls use specialist wall plugs.

Tip – a piece of masking tape applied to the wall before marking the fixing holes will stop the drill wandering. Take care when using power tools - beware of hidden cables or pipes when drilling. The use of a residual current device (RCD) is recommended.

1. Offer up the product to the wall in the desired position to ensure there is enough space for installation.
2. Loosen the grub screw on the product so that the wall fixing bracket can be removed.
3. Using a pencil, mark drill holes in the desired position on the wall (Diagram 1). For products with more than one wall fixing bracket, it is recommended that a spirit level is used to ensure that both sets of drill holes are level.
4. Using a 6mm drill bit, drill holes in the positions marked, deep enough to fit the wall plugs supplied.
5. Using the wall plugs and screws provided, secure the wall fixing bracket(s) to the wall. (Diagram 2)
6. Locate the product onto the wall fixings until flush with the wall and tighten the grub screw. (Diagram 3)
7. The product should now be securely fixed to the wall and ready for use.

AFTERCARE

We recommend that the product is cleaned with a soft, damp cloth to prevent scratches on surfaces. DO NOT use metal cleaners or other abrasive cleaning products as this may also damage the surface of the product.

