

Please follow these fixing and care instructions to ensure your product is fitted safely and retains its high quality finish. This instruction leaflet applies to the following:

AD108541 Premium Telescopic Curved Rod

Fixing Pack Contents

- (A) Fixing Screws x 4
- (B) Wall Plugs x 4
- (C) Cavity Wall Plugs x 4
- (D) Hex Head Key x 1

Tools Required

Drill; 6mm masonry drill bit (6mm ceramic drill bit optional);
Cross-head screwdriver; Pencil; Spirit level; Hex Head Key (Supplied)

KEEP DIY TOOLS OUT OF THE REACH OF CHILDREN

Home Safety Advice

Always take care when using an electric drill, particularly in the bathroom.

Always check for hidden cables and pipe work before drilling and take extreme care if there is any water in the working area.

Always wear suitable eye protection when drilling.

If the product is to be fitted on a ceramic tiled wall, a ceramic drill bit should be used.

Always ensure that the drill hole passes through the central tiled area rather than through the grouted area.

To prevent unnecessary damage to the tile, mask the area around the hole with tape before drilling.

Do not strike product with hard or sharp objects.

Do not use product as a grab bar.

Fixing Instructions

1. Select desired position of the rod and mark centres of the mounting holes using the wall brackets as a template (See Fig 1). The brackets have been designed to be fitted with the wall fixing holes in a vertical position. Please ensure the brackets are level.
2. Using a 6mm masonry drill, drill the holes in the marked positions to a depth of 40mm. If drilling through tiles, please pre-drill using a ceramic drill bit.
3. Insert the wall plugs to the surface of the wall. If fitting to a tiled surface, the wall plugs should be inserted below the surface of the tile to avoid cracking. Screw the wall brackets in position.

IMPORTANT: If inserting cavity wall plugs please take care when threading into the wall surface. Do not screw into position too quickly as this may result in the sections of plaster being pulled off the wall, which could weaken the bracket fixing.

4. Place the connection brackets, with the grub screws positioned upwards, onto the rail ends and loosely secure in position using the hex head key supplied. (See Fig.2)
5. Extend the telescopic rail to the desired length and locate into the wall brackets. Secure in position by tightening the screws located at the top and bottom of the wall bracket using a cross-head screwdriver. (See fig.3)
6. Check the rail is level and adjust if required by loosening the grub screws on the connection brackets. Fully tighten the grub screws when level.

Product Care Advice

To retain the best quality finish, clean product regularly with a soft damp cloth.
Do not use abrasive or chemical cleaners, at these will damage the product.

