

## **AFTERCARE INSTRUCTIONS**

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

Occasionally wipe the surfaces with a soft, damp cloth and dry with a soft Dry cloth. Do not use any abrasive cleaning agents or materials.

## **GUARANTEE**

All products are manufactured to the highest standards and a 5-year guarantee covers any defect in manufacture.

## **CONTACT DETAILS**

If you require further assistance please contact Heritage Sales and Technical Enquiries:

**Sales:** 0844 701 8501

**Technical:** 0844 701 8503

**Email:** [technical@heritagebathrooms.com](mailto:technical@heritagebathrooms.com)

**Website:** [www.heritagebathrooms.com](http://www.heritagebathrooms.com)

**Heritage Bathrooms**  
**Unit 6 Albert Road**  
**St Philips Central**  
**Bristol**  
**BS2 0XJ**



**HERITAGE<sup>®</sup>**  
**BATHROOMS**

## **Heritage Ornate Brackets (CPC30 / CPA30)**



© Heritage Bathrooms 2010

## **Fitting Instructions & Contents List**

Before starting any installation project please consider:

Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget:

- Wear eye protection
- Unplug equipment after use



**Please keep these instructions for future reference and request of replacement part**

These brackets are intended to be used in conjunction with other products, such as cloakroom basins, corner basins and high level cisterns from the Heritage range.

These brackets are for Decorative purposes **ONLY** and should be used with some cloakroom basins, some corner basins and with high level cisterns

### **INSTALLATION**

Fix your sanitary ware item to the wall using the fixing method as shown with your ceramic product.

Slide bracket into position and mark where the screw holes will be with a pencil.

Remove bracket from the wall and drill the holes.

Before starting any installation project please consider:

Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget:

- Wear eye protection
- Unplug equipment after use



Fix the bracket to the wall using suitable fixings appropriate for the wall type.

### **IMPORTANT!**

**THESE BRACKETS SHOULD NOT BE USED TO SUPPORT THE FULL WEIGHT OF YOUR CERAMIC SANITARY WARE PRODUCT.**

### **ILLUSTRATION DIAGRAMS**



© Heritage Bathrooms 2010

