



Heritage Freestanding Vanity Units

Fitting Instructions & Contents List

Before starting any installation project please consider:

Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget:

- **Wear eye protection**
- **Unplug equipment after use**



Please keep these instructions for future reference and request of replacement parts

Thank you for selecting Heritage, All products must be thoroughly inspected prior to installation. Damaged goods cannot be replaced once installed. To ensure this product is installed correctly, please read through these instructions before you begin.

Before attempting to install any Heritage furniture, always ensure the following:

- **The product has been delivered complete**
- **There are no concealed electricity cables, water or gas where you are drilling.**
- **Use safety equipment as necessary**
- **The product is heavy, use correct lifting techniques**

IMPORTANT: Should any cutting of the product be required i.e to fit around skirting or pipe work, this must be re-sealed with a suitable water resistant sealant, to prevent possible water damage to the surface finish/product.

Installation

- 1. This unit may be fixed to the wall using angled brackets (Not Supplied).**



Before starting any installation project please consider:

Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget:

- **Wear eye protection**
- **Unplug equipment after use**

- 2. Hold the cabinet in the required location and with a pencil, mark the wall through the holes in the angled brackets.**
- 3. Remove the cabinet and drill holes of an appropriate size to accept the necessary screws.**
- 4. Lift the cabinet back into position and screw to the wall.**
- 5. Locate and secure the basin.**
- 6. Determine where you want to fit the door handles and drill the doors in the desired position for the door handles, Screw the door handles onto the doors**
- 7. NOTE: Use silicon sealant where necessary to ensure the basin edges are sealed and water tight to the furniture.**
- 8. You may need to adjust the alignment and action of the door using the hinge adjustment screws.**

Applicable to all Heritage freestanding vanity units.

Bowfront medium vanity unit

Dorchester square vanity unit

Blenheim vanity unit

Classic vanity unit (Blenheim & Dorchester Square)

Caring for your furniture

All our products are finished with durable lacquers and paints, which are designed to be resistant to liquids, staining and warm objects. In order to ensure that your newly purchased Heritage furniture maintains its finish for many years to come, we advise that you take note of the following, please see aftercare instructions on the following page.

Aftercare Instructions.

Your fitting has a high quality finish and should be treated with care to preserve the visible surface. Occasionally wipe the surface with a soft damp cloth and dry with a soft dry cloth. Do not use any abrasive cleaning agents or materials.

Guarantee.

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

Contact Details.

If you require further assistance please contact Heritage Sales and Technical Enquiries:

Sales: 0844 701 8501
Technical: 0844 701 8503
Email: technical@heritagebathrooms.com
Website: www.heritagebathrooms.com

Heritage Bathrooms
Unit 6 Albert Road
St Philips Central
Bristol
BS2 0XJ

