



1. Measure the distance required between the ceiling and the top of the glass panel to be fitted (Measurement A)
2. With the unit loosely assembled and each end pushed fully in, offer the unit inbetween the glass and the ceiling to ensure the glass is plumb, the arm is plumb and the unit is long enough.
3. mark on the ceiling the location for the mounting hole (H)
4. Attach the ceiling bracket through hole (H) using appropriate fixing methods for the ceiling.
5. Re-assemble everything and tighten all grub screws to the glass, ceiling bracket and arm joint.
6. Test all joints for tightness before use.

