

## **AFTERCARE INSTRUCTIONS**

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surface finishes will wear if not cleaned correctly, the only safe way to clean your mixer is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting, even the non-scratch cleaners. **NOTE: Never use abrasive detergents or disinfectants or those containing alcohol, hydrochloric acid or phosphoric acid.**

## **GUARANTEE**

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

**NOTE: The 5-year guarantee on the cartridge is invalidated if damaged by any waterborne debris.**

**All products must have access for servicing or replacement during the life of the product.**

In the interests of continuous product development we reserve the right to alter specification as necessary

## **PRODUCT CODE:**

**PRODUCT IDENTIFICATION CODE LASER ETCHED ON PRODUCT**  
Installer please fill in code here \_\_\_\_\_.(Where applicable)

TELEPHONE HELPLINE! +44 (0)844 701 6273

Bristan Group Limited  
Birch Coppice Business Park  
Dordon  
Tamworth  
Staffordshire  
B78 1SG  
UK  
A Masco Company  
Website: [www.bristan.com](http://www.bristan.com)  
Telephone: +44 (0) 844 701 6274  
Facsimile: +44 (0) 844 701 6275  
Email: [enquire@bristan.com](mailto:enquire@bristan.com)

# BRISTAN

## **Bath Shrouds**

## **Fitting Instructions**

**Please keep these instructions for future reference and request of replacement part**

Bath shrouds are designed to cover pipework, which feeds up from under the floor, to taps or mixers that are fitted to and supported by freestanding roll top style bath. If it is necessary to shorten the shrouds, it must be done from the floor end.

## **INSTALLATION**

**NOTE: - Installation instructions are only a guide, and the order in which the installation is carried out may be altered to suit on-site conditions.**

1. Identify all components and check for completeness, particularly before commencing installation.
  2. Loosely, to allow vertical movement, arrange taps or mixer (1) to the bath (2) following their own instructions, with the washer (3) between and the backnut (4) below the bath. Screw the flanges (5), knurled diameter uppermost, onto the tails of the taps or mixer.
  3. Position the floor plates (6) directly under the tap or mixer tails, mark out screw holes, drill and using rawl plugs if necessary, screw plates to the floor.
  4. The connector (7) supplied can be brazed onto 22mm pipe work (not supplied) to create the vertical feed through the shroud to the taps or mixer. Use a suitable length to allow sufficient movement to aid assembly and to ease further connections below the floor.
- Please Note: - Horizontal feed pipe under floor must have a degree of freedom to move up and down.**
5. Slide shrouds (8) over and connect the vertical pipes to tails using the connector washers (9). Connect vertical pipe work to under floor pipe work and test by turning on fitting and letting it run for a few minutes to check all joints and connections for leaks.
  6. Secure the taps or mixer to the bath using the backnuts (4). Then secure the shrouds in position by locating them onto the floor plates and screwing the flanges (5) down the tap or mixer tails.
  7. See back page for aftercare instructions.

### **PLEASE NOTE:**

In the unlikely event you find a part missing, please contact our Customer Service helpline on **0844 701 6273** for immediate dispatch of part

## **INSTALLATION DIAGRAMS**

