

Warnings:

Fit in accordance with manufacturers instructions.

Do not place very hot or very cold items against or in close proximity to glass surfaces unless an adequately thick insulating material is used to prevent such items from coming into contact with the glass.

Do not strike the glass with hard or pointed items.

Do not sit or stand upon horizontal glass surfaces.

Wear suitable eye protection when drilling. When using power tools near water the use of a residual current device is advised for added protection against electric shock.

Beware of hidden pipes or power cables. Take care when drilling on glazed tile surfaces in case drill slips.

Cleaning:

When cleaning glass panels or mirrors use a damp cloth or chamois leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substance containing abrasives since these substances scratch glass.

Complies with BS 7449: 1991.

Mirror thickness 4mm film backed.

Model ref: Slimline Oak Cab. Batch CK01.10

If glass component is chipped or broken replace with glass of the type described on this label. Consult the manufacturer, retailer or agent with regard to obtaining a manufacturing specification and shape for replacement glass quoting the model number, and batch number or date of manufacture.

Supplied by Wireworks PO Box 59208 London NW3 9ES.

www.wireworks.co.uk

Slimline Oak Bathroom Cabinet

.wireworks

Thank you for purchasing this Oak Bathroom Cabinet.

Please read the instructions and warnings carefully before use to ensure safe and satisfactory operation of this product. Keep these instructions for further use.

Instructions for use:

The Cabinet is supplied with screws and wall plugs suitable for a stone or brick wall. For other wall types (eg. hollow plasterboard) alternative fixings will be required. If in doubt, consult a qualified person.

The door hinge fixing screws may become loose in transit and should be checked and tightened if necessary before use.

Fitting Instructions:

You will need a power drill, a masonry drill bit, a medium cross-head screwdriver, a spirit level and pencil to install this product.

Ensure the wall surface is of suitable strength and construction before hanging the cabinet.

1 Position cabinet against wall using spirit level to check alignment.

2 Mark using a pencil the positions for the four wall plug holes from inside the cabinet.

3 Drill holes to depth of 50mm and push in wall plugs so they are flush.

4 Hold cabinet upto wall and fix screws securely from inside the cabinet to the wall plugs.

5 Push brackets into pre-drilled holes inside the cabinet at required height and fit shelves.

Some cabinets include clip hinges so doors can be removed easily during instalation.

Oak Cabinet

x 4 Wall Plugs



x 4 Screws



x 8 / 12 Shelf Brackets



x 2 / 3 Glass Shelves

