

## **AFTERCARE INSTRUCTIONS**

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surface finishes will wear if not cleaned correctly, the only safe way to clean your waste is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids will damage the surface of your fitting even the non-scratch cleaners.

## **GUARANTEE**

All products are manufactured to the highest standards and a 5 year guarantee covers any defect in manufacture.

As gold and special effect finishes are softer than chromium plate, special care must be taken when cleaning, a 3 year guarantee covers these finishes.

**PRODUCT NAME:**  
**PRODUCT CODE:**

**TELEPHONE HELP LINE! 0844 701 8503**

Web Site: [www.heritagebathrooms.com](http://www.heritagebathrooms.com)  
Telephone: 0844 701 8503

**HERITAGE®**  
**BATHROOMS**

## **Basin Waste**

## **Fitting Instructions**

**Please keep these instructions for future reference**

## INSTALLATION

**N.B. Before Installation, please write the name and product code of your fitting in the spaces provided overleaf. This will ensure a speedier service if you should need to phone the help line.**

1. Identify all components and check for completeness.
2. Fit the waste body (5) and foam washer (6) into the basin.
3. Fit the rubber washer (7) underneath the basin as shown on the diagram, secure by tightening backnut (8).  
Use a pure Silicon sealant where necessary.
4. Fit the stay (2) to the basin with the nut (1) provided.
5. Check all joints and connections for leaks.
6. See over the page for aftercare instructions.

## COMPONENTS

1. Stay nut
2. Basin stay
3. Chain assembly
4. Plug
5. Waste body
6. Rubber washer
7. Fibre washer
8. Backnut

