

Shower Panel SL1302 Installation Guide

Refer to the technical diagram to choose the proper location for your shower panel, you can adjust the column's vertical position based on the person's height. (Measurements given in the technical diagram are based on the average human height. 68 5/7")

Flat wall Installation

1. Insert the overhead shower (7) into the main body (9), secure them with screws (6).
2. Choose the proper location for your column and mark the drill holes $\text{Ø}5\text{mm}$ (1). Drill the holes on the distance 17mm and 20mm from each other. Drill the holes on the distance 450mm from upper holes to lower holes.
3. Insert wall anchors (2) inside the holes (1). Fix the bracket (3) with stainless steel washer (4) and screws (5).
4. Place mesh gaskets (17) into the flexible hot (15) and cold (16) water supply line.
5. Connect the flexible hot (15) and cold (16) water supply lines to hot (18) and cold (19) water outlets (supplied by your plumber) accordingly.
6. Hold up the column (9), hang the column on the bracket (3) on the wall.
8. Attach the flexible shower hose (13) to the column body placing rubber washer (11) in nut (14).
11. Connect the hand shower (9) to the hose (13) placing the rubber washer (11) in the fastening nut (12).
12. Set the hand shower (9) on the holder (10).

NOTE: ① Do not forget to use the rubber washers to prevent leakage on the connection.

② If you find that pressure or water volume is unusual, please clean the mesh gaskets (17) regular.

Please, make sure that none of the hoses are bent or kinked after final installation. Check water connections for proper flow; make sure there is no leakage.