

# WC 871205 - Medway Stainless Steel Sliding Door Cabinet



Thank you for purchasing this Croydex product. Please follow the fixing and care instructions to ensure your cabinet is fitted safely and retains its high quality finish. Please retain this leaflet for future reference.

## Tools required - not supplied

Pencil; Tape Measure; Philips Screwdriver; Drill; 8mm Drill Bit, 8mm Ceramic drill bit (optional).

## KEEP DIY TOOLS OUT OF THE REACH OF CHILDREN

**NOTE: Wall plugs are supplied for a solid wall fixing only. For cavity walls or plasterboard use specialist fixings available from all good DIY stores.**

## Home Safety Advice

- It is recommended that two people fit this product to ensure that it is fitted safely.
- Always take care when using power tools, particularly in the bathroom.
- Always check for hidden cables and pipework before drilling and take extreme care if there is any water in the working area.
- It is advisable to use a residual current circuit breaker (RCCB).
- Always wear suitable eye protection when drilling.
- If the product is to be fitted on a ceramic tiled wall, a ceramic drill bit should be used.
- Always ensure that the drill hole passes through the central tiled area rather than through the grouted area. To prevent damage to the tile, mask the area around the hole with tape before drilling.
- Do not strike the product with hard or sharp objects.

## Product Care

To retain the best quality finish, clean product regularly with a soft damp cloth. Do not use abrasive or chemical cleaners as these will damage the product.

## Fixing Instructions

1. Hold the cabinet against the wall in its desired location. Check that the cabinet is straight and level using a spirit level. Slide the door open and mark the wall through the holes in the back of the cabinet with a pencil.
2. Using a 8mm masonry drill, drill the holes in the marked positions to a depth of 45mm and insert the wall plugs into the holes in the wall.
3. Hold the cabinet against the wall and align the holes in the back of the cabinet with the wall plugs. Insert the mounting screws through the holes in the back of the cabinet and screw into the wall plugs to complete the assembly. **DO NOT OVERTIGHTEN.**

For details of the other items in the Croydex range please visit our website: [www.croydex.com](http://www.croydex.com)

Croydex Limited, Central Way, Andover, Hants, SP10 5AW, UK  
Tel: +44 (0) 1264 365881  
Fax: +44 (0) 1264 356437  
E-mail: [info@croydex.co.uk](mailto:info@croydex.co.uk)