

Installation instructions



	<p>Components as below:</p> <p> Bracket (1 PCS)</p> <p> Shower Head (1 PCS)</p> <p> Inlet Hose (1 PCS)</p> <p> M6x500 Connect pole (4 PCS)</p> <p> Rawl plug (M6 female) (4 PCS)</p> <p> M4x40 Flat Screw (4 PCS)</p> <p> M6 Hexagon Nut (12 PCS)</p>		<p> Bracket Dimension</p> <p>STEP 1</p>	<p> Drill 4 holes according to above dimension on the ceiling, hole size $\varnothing 8 \times 30$ mm. Insert 4 rawl plugs</p> <p>STEP 2</p>
	<p> Rawl plug M6x500 Connect pole</p> <p>Screw 4 M6x500 connect pole in rawl plug</p> <p>STEP 3</p>		<p> M6 Nut Bracket</p> <p>Install bracket to Connect pole</p> <p>STEP 4</p>	
<p> Inlet hose Bracket Ceiling 100mm-500mm</p> <p>Connect to inlet hose</p> <p>STEP 5</p>	<p> Tighten screw nut above and bottom of bracket</p> <p>STEP 6</p>			
<p> Shower head connect to inlet hose</p> <p>STEP 7</p>	<p> Fix shower head to bracket</p> <p>STEP 8</p>			
<p>1. Be careful not to collide. 2. Water pressure under 3 bar. 3. In the absence of professional and technical equipment, do not dismantle and disassembly.</p>				

Victorian Plumbing

Diamond House. 41, Stephenson Way. Formby Business Park Formby. England. L37 8EG

Tel: 0044 800 862 0878

Website: www.victorianplumbing.co.uk