

Bath shrouds are designed to cover pipework, which feeds up from under the floor, to taps or mixers that are fitted to and supported by freestanding roll top style bath. If it is necessary to shorten the shrouds, it must be done from the floor end.

INSTALLATION

NOTE: - Installation instructions are only a guide, and the order in which the installation is carried out may be altered to suit on-site conditions.

1. Identify all components and check for completeness, particularly before commencing installation.
2. Loosely, to allow vertical movement, arrange taps or mixer to the bath following their own instructions, with the washer between and the backnut (4) below the bath. Screw the flanges (5), knurled diameter uppermost, onto the tails of the taps or mixer.
3. Position the floor plates (6) directly under the tap or mixer tails, mark out screw holes, drill and using rawl plugs if necessary, screw plates to the floor.
4. The connector (7) supplied can be brazed onto 22mm pipe work (not supplied) to create the vertical feed through the shroud to the taps or mixer. Use a suitable length to allow sufficient movement to aid assembly and to ease further connections below the floor.

Please Note: - Horizontal feed pipe under floor must have a degree of freedom to move up and down.

5. Slide shrouds (8) over and connect the vertical pipes to tails using the connector washers (9). Connect vertical pipe work to under floor pipe work and test by turning on fitting and letting it run for a few minutes to check all joints and connections for leaks.
6. Secure the taps or mixer to the bath using the backnuts (4). Then secure the shrouds in position by locating them onto the floor plates and screwing the flanges (5) down the tap or mixer tails.
7. See back page for aftercare instructions.

INSTALLATION DIAGRAMS

