

AFTERCARE INSTRUCTIONS

Your fitting has a high quality finish and should be treated with care to preserve the visible surfaces.

All surface finishes will wear if not cleaned correctly, the only safe way to clean your product, is to wipe with a soft damp cloth. Stains can be removed using washing up liquid. All bath cleaning powders and liquids can damage the surface of your fitting even the non-scratch cleaners.

GUARANTEE

All products are manufactured to the highest standards and a 10-year guarantee covers any defect in manufacture.

NOTE: - The 10-year guarantee on the valve is invalidated if damaged by any waterborne debris.

CONTACT DETAILS

If you require further assistance please contact Heritage Sales and Technical Enquiries:

Sales: 0844 701 8501

Technical: 0844 701 8503

Email: technical@heritagebathrooms.com

Website: www.heritagebathrooms.com

Heritage Bathrooms
Unit 6 Albert Road
St Philips Central
Bristol
BS2 0XJ



HERITAGE[®]
BATHROOMS

Deco Cistern Lever (CDC01)



© Heritage Bathrooms 2010

Fitting Instructions & Contents List



Before starting any installation project please consider:

Prior to drilling into walls, check there are no hidden electrical wires, cables or water supply pipes with the aid of an electronic detector. If you use power tools do not forget:

- Wear eye protection
- Unplug equipment after use

Please keep these instructions for future reference and request of replacement part

INSTALLATION

1. Identify all components and check for completeness, particularly before commencing installation.
2. To remove the old handle, remove cistern lid.
3. Loosen lifting arm retaining screw and remove lifting arm from handle shaft.
4. Disconnect lifting arm from the siphon plunger hook.
5. Loosen and remove backnut from the handle shaft. It may be necessary to remove a split pin from the shaft first. Pull handle from cistern.
6. To fit the new handle, remove lifting arm (4) and plastic snap ring (5) from the handle shaft (2) and the plastic backnuts (6) from the threaded sleeve (7).
7. Remove threaded sleeve from handle shaft and mount in cistern using plastic backnut. Tighten firmly.
8. Insert handle shaft through sleeve and replace snap ring.
9. Connect plunger hook to lifting arm in the appropriate hole so that when lifting arm is mounted on handle shaft it is directly above the siphon plunger.
10. Tighten retaining screw (3) on lifting arm.
11. See the back page for aftercare instructions

COMPONENTS

1. Handle
2. Handle Shaft
3. Lifting Arm Retaining Screw
4. Lifting Arm
5. Plastic Snap Ring
6. Plastic Backnut
7. Threaded Sleeve

