

Installation instructions



	<p>Components as below:</p> <p>Bracket (1 PCS)</p> <p>Shower Head (1 PCS)</p> <p>Inlet Hose (1 PCS)</p> <p>M6x500 Connect pole (4 PCS)</p> <p>Rawl plug (M6 female) (4 PCS)</p> <p>M4x40 Flat Screw (4 PCS)</p> <p>M6 Hexagon Nut (12 PCS)</p>	<p>Bracket Dimension</p> <p>STEP 1</p>	<p>Drill 4 holes according to above dimension on the ceiling, hole size $\varnothing 8 \times 30$ mm. Insert 4 rawl plugs</p> <p>STEP 2</p>	
	<p>Rawl plug M6x500 Connect pole</p> <p>Screw 4 M6x500 connect pole in rawl plug</p> <p>STEP 3</p>	<p>M6 Nut Bracket</p> <p>Install bracket to Connect pole</p> <p>STEP 4</p>		
	<p>Inlet hose Bracket Ceiling</p> <p>Connect to inlet hose</p> <p>STEP 5</p>	<p>Tighten screw nut above and bottom of bracket</p> <p>STEP 6</p>		
	<p>Shower head connect to inlet hose</p> <p>STEP 7</p>	<p>Fix shower head to bracket</p> <p>STEP 8</p>		
	<p>Victorian Plumbing Diamond House. 41, Stephenson Way. Formby Business Park Formby. England. L37 8EG</p> <p>Tel: 0044 800 862 0878 Website: www.victorianplumbing.co.uk</p>		<p>1. Be careful not to collide. 2. Water pressure under 3 bar. 3. In the absence of professional and technical equipment, do not dismantle and disassembly.</p>	