

Before you begin:

- 1. Check the chosen wall space for any pipes/cables prior to drilling
- 2. Unpack the product then read these instructions before proceeding. Inspect the product for damage. If any damage is found, contact our Customer Relations team.
- 3. Make sure that all components are present prior to installation.

Installation:

Step 1:

(1b)

- Place the hanger bracket at the desired height, then make a mark across the top the bracket to the wall.
- At the back of the hanger bracket, measure the distance between the two fixing points. Apply the measurements to the wall below the original marking. Ensure all the markings are level using a spirit level.



2b





Step 3:

- Using the screws provided, screw into the rawl plugs leaving at least a 5mm protrusion of the screw head.
- Carefully insert the hanger bracket onto the screw heads. Ensure that the bracket is fully slotted into place.
- Ensure the hanger bracket is level using a spirit level.



Step 2:

• Using an appropriate sized drill bit, carefully drill the holes in the wall then insert the rawl plugs.



Diagrams are for illustration purposes only. Your towel stacker may superficially differ from this drawing however the installation guide steps still apply.

victorian plumbing.co.uk