

Installation and operation instruction



- Place two plastic expansion screws (1) on the wall, and then use two SS304 self-tapping screws (2) to fix the valve body (3) on the wall (pay attention to the position and levelness between the valve body, floor and wall).
- Connect the cold \hot water inlet pipe to the two G1/2 inlet holes of the valve body. Connect shower pipe to the middle G1/2.
- Decorate the wall tile surface (pay attention to the distance between wall and Valve body (1) it should be 30 to 50mm).
- Pull out the two plastic protective sleeves (11).
- Unscrew the M5 locking screw (8) with the S2.5 Allen key (10) , then remove the handle (7).
- Cartridge sleeve (4) is covered by decorative panel (6).
- Put the handle (7) on the stem of the spool (5), turn the handle (7) to the left side of the spool clockwise so that the handle can align word H on the panel (to be pull out again if no alignment), tighten the M5 screw (8) with the S2.5 wrench (10) , and finally install the rubber plug (9) in the handle hole.
- Put the handle (7) on the stem of the spool (5), turn the handle (7) to the right side of the spool counter-clockwise so that the handle (7) can align word C on the panel (to be pull out again if no alignment), tighten the M5 screw (8) with the S2.5 wrench (10) , and finally install the rubber plug (9) in the handle hole.
- Check all joints & connections for leaks.

Victorian Plumbing

Diamond House.41,Stephenson Way.Formby Business Park Formby.England.L37 8EG

Tel:0044 800 862 0878

Website:www.victorian plumbing.co.uk

