

# STAND PIPE INSTRUCTIONS

1. GRUB SCREW
2. COLLAR
3. TAP TAIL
4. TAP CONNECTOR (NOT SUPPLIED)
5. BASE PLATE
6. STAND PIPE
7. SEALING WASHER (NOT SUPPLIED)

