

Replacing filter on BOI002

To complete this installation there is no need to isolate the water supply if the system has been installed correctly, but there may be some water in the system. Please take precautions to protect furniture etc.

Step 1

Grab the body of the filter and twist anti clockwise

Step 2

Lower the body away from the top

Step 3

Remove new filter from packaging, insert into the top fixing and twist in clockwise. This will lock into position.

Installation complete. Please note if the replacement filter does not look like image 3 below you have not received the correct part.

Image 1



Image 2



Image 3

