

BC109-ST5 Dolphin Valera Hairdryer

User Manual

Please read carefully before use



Installation instructions for your heavy duty hair dryer

Your hair dryer has been tested before leaving the factory, If any part should be damaged in transit, please return it to us for immediate replacement.

Each carton contains:

- a. Hair dryer
- b. Wall bracket with wall label
- c. Styling nozzle
- d. 2 screws and wall plugs.

Siting: This hair dryer is not to be used in bathrooms or areas near water.

The hair dryer must not be installed in a position where, when fully extended, can be reached by a person using a bath or shower.

Wiring

The hair dryer comes with a UK plug fitted, Should you wish to permanently connect the dryer to the mains then proceed as follows:

The 220/240 volt 50Hz supply must be connected to the Hair Dryer via a double pole fused isolator having a contact separation of at least 3mm between poles. In order to guarantee additional protection, it is strongly recommended that a differential breaker with an intervention current not greater than 30 mA is installed in the electrical system which feeds the device. For further information, contact a qualified electrician.

Reduce the wire length to the dryer to ensure it will not touch the ground should it get dropped,

The wires in the mains lead must be connected to the fused isolator in the following way:

The brown lead to the terminal marked: L

The blue lead to the terminal marked: N

Inspection

The coiled cable to the hair dryer should be checked regularly, especially in high usage areas, for any signs of wear, splitting or vandalism, especially at both ends. The hair dryer case should be checked regularly for any damage and the safety warning labels are still in place.

Safety

- Plug the hairdryer into an alternating current outlet only, and make sure that the voltage for your electricity supply is the same as that indicated on the rating plate of the appliance.
- Do not use your hairdryer in the bath or under the shower, or near basins or other vessels containing water.
- Do not immerse in water or other liquids.
- Never put the appliance in a place where it could fall into water or in other liquids.
- Do not try to recover an electric appliance fallen into water, but unplug it immediately from the mains supply.
- Turn the hair dryer off before putting down.
- Unplug the appliance when not in use, but never do it by pulling the cord.
- Remember to check regularly that the air inlet and outlet grills are clean.
- Allow your appliance to cool before storing away and do not wrap the supply cord around the hairdryer in storage.
- Do not use the dryer if it does not work properly, if it dropped or if the supply cord is damaged. Do not try to repair.
- Children should be supervised to ensure that they do not play with the appliance.

Important

This hairdryer conforms to the safety regulations regarding electrical appliances. This hairdryer has a safety cut-out which will operate in case of overheating. The dryer will re-set itself after being left to cool for a few minutes, but check the air inlet and outlet grills are clear before continuing to use the dryer.

This product conforms to the radio interference suppression requirement: EEC directive 89/336.

Switch operation.

Top switch:

- 1=Low heat
- 2= Medium heat
- 3= High heat

Bottom switch:

- 0 = Off
- 1 = Low speed
- 2 = High speed

Pressing the blue button while the dryer is running, switches the heat to a cool setting.

Cool air helps set the style, so always finish with the cool setting for a longer lasting, more effective result.

Styling nozzle

Fit the flat-air styling nozzle onto the hairdryer for added styling control whilst drying.

Filter

Before cleaning, isolate from the mains. The hairdryer is equipped with a removable filter grill, which prevents dust particles and hair from being sucked in by the fan. This grill can be washed under running water. To remove it, twist and remove. After cleaning the grill, make sure that it is completely dry before placing it again onto the hairdryer.

Guarantee

This professional hair dryer supplied is considered a consumable item and is guaranteed against faulty workmanship and materials for 6 months. This does not cover vandalism, improper use, or non compliance with these instructions. Any physical damage will be classed as vandalism.

LEAVE THESE INSTRUCTIONS WITH THE PERSON RESPONSIBLE FOR THE SAFE WORKING OF THIS HAIR DRYER.



Bell-Chem Products Company

Southpoint, Compass Park, Bodiam,
Robertsbridge TN32 5BS

Tel: 01424 202224

Fax: 01424 205200

www: dolphindispensers.co.uk

info@dolphindispensers.co.uk