


PUSH BUTTON PLATE FIXING INSTRUCTION



REMOVE THE FACIA FROM THE CABINET.
CUT A 205mm x 100mm RECTANGULAR HOLE IN THE REQUIRED POSITION OF THE FACIA BOARD

FIX THE FIXING PLATE TO THE FACIA USING THE SCREWS PROVIDED

CONNECT THE FLUSH VALVE CABLE BOX TO THE BACK OF THE BUTTON PLATE. THEN CLIP THE PUSH BUTTON COVER PLATE ONTO THE FIXING PLATE. REPLACE THE FACIA ONTO THE CABINET.