


Before you start

It is recommended that the unit and basin are secured to a suitably reinforced wall to ensure stability. This can be done through the back rail (fixings not included.)

Hinge Adjustment

1.




2.

To make adjustment 1 (see Drawing 1) tighten/loosen adjustment screw A.

To make adjustment 2 (see Drawing 1) simply turn screw B

Button C is the quick release, press this on both hinges to remove a door by releasing the hinges from their mounting plates.



Fitting Ceramic Basin

Once the basin has been plumbed in finish by securing to the washstand using a silicone sealant (not supplied).

Furniture Aftercare Instructions

As with all wooden furniture, this product should be treated with care.

<p>We recommend...</p> <p>Wipe away any water splashes or condensation after use. Excessive exposure to water will deteriorate the furniture.</p> <p>All bathrooms should be well ventilated with a suitable extractor fan.</p> <p>Clean with a soft damp cloth only.</p> <p>Use a wax free polish if one must be used.</p> <p>For removal of lime scale deposits use a suitable proprietary cleaner. Test on an inconspicuous area first.</p>	<p>Please DO NOT...</p> <p>Do not scrub or scour</p> <p>Do not use abrasive cleaning agents</p>
---	--

Replacement components - Should you require any replacement components for this product please contact Roper Rhodes using the contact details below.