

Use with product codes:

WGABBLE;WGABDOR;WGABVIC;WGABWYN;WGABWYN8;WGABCLA

This installation guide is additional to the Washstand Installation Guide. Please refer to parent part installation guide.

Pack Contents		
No.	Description	Qty
1	Glass Shelf	1
2	Shelf Rests (all-on-one)	2
3	Shelf Wall Brackets	2
4	Hexagonal Key	1

2

Insert the shelf rests into the holes at the back of the two legs.
Note: On Claverton Washstand, the shelf rest inserts on the inner sides of the legs, not back.

3

Carefully rest the glass shelf on the shelf rests and using a spirit level to level the glass shelf up horizontally at the back, and also from back to front, mark the wall from the top and bottom of the shelf around 65mm inwards from the sides of the glass shelf.

4

Find the centre of the markings and drill suitable holes for the fixings to be used. Secure the brackets in the wall.

5

Fit the Glass Shelf in the rear brackets and resting on the front dowels and tighten up the brackets at the rear using the supplied Hexagonal Key.
Caution: Do not overtighten.

For guarantee and caring for your product, please refer to the sections in the parent product installation guide.