

WhirlPool Installation & Cleaning Guide



Electrical Connections



Grounding (Earth) is required. The unit should be installed and grounded by a qualified electrician.

The unit should be connected to source voltage of 220 VAC With Frequency of 50Hz.

Cleaning



Don't clean the tub and accessories with hard or coarse material to avoid any scratches.



Don't clean the tub and accessories with organic solvents to avoid any damages.




Clean the surface with a soft cloth and soapy water.



It's not recommended to leave water in the tub for long time or use this tub for washing purpose. Pls drain off the water after the bath and disconnect the power supply.

Valencia FST Whirlpool System

Mounting Instructions



No. of Air jets 12
Power of Air blower 700W

