

Assembly instructions

1. Identify all components are present prior to installation
2. Checking all of parts if leaking water after installment

