

SIGMA


Large Soap Basket CB20.02 & Large Corner Basket CB40.02 Fitting & Care Instructions

Before assembling this product please take time to read the following instructions carefully. If you are in any doubt please consult a qualified person.

The wall fixings supplied with this product are suitable for fixing to a solid wall only. For plasterboard use specialist wall fixings. Seek specialist advice about the suitability of fixings to be used.

Tools Required -Pencil Drill 6mm Drill Bit Screwdriver Masking Tape Tape Measure Spirit Level





- Remove the screw cover caps (part D) and store safely.
- Position the basket in the desired location on the wall. Use a spirit level to ensure the product is level.
- Using a pencil inserted through the holes in the wall mounting bosses and mark the screw locations.
- Tip: On tilled surfaces a piece of masking tape will make marking and drilling the holes much easier.


Caution! Before drilling check for hidden cables and pipes.


Take care using power tools especially near water, the use of a residual current device (RCD) is recommended.

- Drill holes using a 6mm drill bit to a depth of approximately 30mm. If used remove any masking tape after drilling.
- Insert wall plugs (part B), it may be necessary to gently tap the wall plugs in using a light hammer, take care not to damage tiles.
- Fasten the basket to the wall using the screws supplied (solid walls only), ensure they are fully tight.
- Replace screw cover caps (part D).

Cleaning -

We recommend using a soft damp cloth only. Do not use metal cleaners or other abrasive cleaning agents.





Should you encounter any problems with this product please contact Customer Services Department
Roper Rhodes Ltd
Brassmill Lane Trading Estate

Bath BA13JF

Tel: 01225 303 900 Fax: 01225 448 877

e-mail: sales@roperrhodes.co.uk web: www.roperrhodes.co.uk