

AARON Riser rail assembly





Installation Instructions


Installers please note these instructions are to be left with the user

FITTING THE AARON RISER RAIL ASSEMBLY









WARNING!

Check there are no hidden cables or pipes before drilling holes for wall plugs. Use great care when using power tools near water. The use of a residual current device (RCD) is recommended when using power tools.

IMPORTANT: The kit should be fitted in the following sequence to allow correct measurement and placement of the bracket holes.

Decide the position for the rail on the wall within the shower area. Proceed as follows:

Offer the lower bracket to the wall.

Note: The lower bracket has a small peg in the riser rail hole.

- Position the bracket and mark the centre hole. Remove the bracket then drill and plug the wall. (An appropriate drill bit should be used. If the wall is plasterboard or a soft building block, appropriate wall plugs should be fitted).
- Replace the bracket to the wall and secure in place using the screw supplied **(fig.1)**.

Note: The locating hole is elongated to allow for some horizontal adjustment.

- Locate the rail into the bracket. Make sure
 it fits properly. The notch in the riser rail
 should be located onto the peg in the
 bracket (fig.2).
- Fit the upper bracket onto the riser rail making sure the rail is vertical. Mark the centre hole. Remove the bracket and rail, then drill and plug the wall.
- Fit the locking assembly to the slider/holder so that the holes align, then slide onto the rail (fig.3).

FITTING THE AARON RISER RAIL ASSEMBLY

 Tighten the holder to the rail. Make sure the tapered thin end of the showerhead holder is in the upper position (fig.4).

The *soap dish is an optional extra and can be purchased from Customer Care, please see No: 6 in the spares section for part numbers.

- Slide the hose retainer onto the bottom of the riser rail (fig.5). *If the soap dish has been purchased please refer to (fig.5a).
- Place the rail onto the lower bracket. Replace the upper bracket onto the rail and secure to the wall with the screw supplied.
- Fit the end caps onto both brackets. The end caps will only fit one way.

FITTING THE HOSE AND SHOWERHEAD


 Feed the flexible hose through the hose retainer (fig.6) so that it acts as a retaining ring (The hose retainer MUST be fitted to comply with Water Regulations).


Note: The holder is slightly tapered and the showerhead and hose will only fit from one direction.


IMPORTANT: It is the conical end of the hose which grips into the holder.


The showerhead will not fit in the holder without the hose attached.

- Screw the flexible hose to the shower outlet and showerhead, making sure the supplied washers are in place at both ends of the flexible hose (fig.7).
- Place the showerhead into the holder and check that it fits correctly **(fig.8)**.









SPARE PARTS

Ref. Description Part Number Kit (without riser rail) 88900000 chrome white †(no soap dish) 88900008 white 88900009 1. Brackets & trims (pair) white 83310440 chrome 83308340 2. Trims (single) white 83310450 chrome 83308350 3. Riser rail – 19mm aluminium 88800008 chrome 88800000 4. Showerhead holder white 83310460 chrome 83308360 5. Hose retainer white 83310480 chrome 83308380

Flexible hoses available in the following sizes:

83310470


83308370

1.00 m in white, chrome and gold 1.25 m in white, chrome and gold


1.75 m in chrome only

6. †Soap dish (optional extra) white


clear



NITRO Single Position Showerhead



Installation Instructions



INSTALLERS PLEASE NOTE THESE INSTRUCTIONS ARE TO BE LEFT WITH THE USER

SINGLE POSITION SHOWERHEAD

This instruction book covers the operation and cleaning of the showerhead.

Your showerhead has a single showering pattern.

CLEANING

Triton recommends that all products are cleaned using warm, soapy water.

Do not use abrasive or aggressive chemical cleaning products as this may affect the product surface and finish and invalidate your quarantee.

Note: The showerhead can be cleaned quickly by simply rubbing your fingers over the faceplate.

Before cleaning, turn off the unit at the mains supply to avoid the shower being accidentally switched on.

IT IS IMPORTANT TO KEEP THE SHOWERHEAD CLEAN TO MAINTAIN THE PERFORMANCE OF THE SHOWER. The hardness of the water will determine the frequency of cleaning. For example, if the shower is used every day in a very hard water area, it may be necessary to clean the showerhead on a weekly basis.

Note: The shower head is not designed to be disassembled.

SPARE PARTS

Ref. Description Part number

1. Single mode rub clean electric showerhead

white 88500027 chrome 88500044