
















INSTALLATION MANUAL








1		2		3		4		5		6		7	 1760mm
D6x30	6Pcs	ST4X30	6Pcs	ST4X12	14Pcs	RF-6Y04	12Pcs	RF-6W01	2Pcs	RF-6X03	4Pcs	RF-6Z02	2Pcs
8	1825mm	9		10		11		12		13		14	
RF-6Z02	2Pcs		2Pcs	RF-6X01	2Pcs	RF-6X02	4Pcs	RF-6W016	2Pcs	RF-6X03	4Pcs	RF-6Z01	1Pair
15		16		17	Optional parts	18	Optional parts	12	1400	1700	Tools:		
RF-6Y02	4Pcs	RF-6Y05	8Pcs	RF-6Y01	6Pcs	RF-6W02	2Pcs	RF-6W017	2Pcs	RF-6W16			RF-6W17






1

		L
1400	1340-1380	
1700	1640-1680	



1-1		5x2
1-2		Ø6x30mm
1-3		1x6

**2**


3



4





5



6-a

Without concealed profile



6-1

Ø3.2mm

6-2

3x6

6-3




4x12

6-4



6-b

With concealed profile



7

Care instructions:
Do not use your shower enclosure within 24 hours of assembly.
Do not use caustic cleaning products or abrasive material when cleaning your shower enclosure.

