


Gothic Traditional Thermostatic Radiator Valve



Rotate the Wheel handle clockwise and anti-clockwise between the first and the fifth line to select the required room temperature.

Technical Specification

- Maximum working pressure: 10 bar
- Maximum pressure differential: 1 bar
- Maximum water temperature: 100°C
- Maximum ambient temperature: 50°C
- Temperature adjustment range: 12 to 30°C

When installing a thermostatic radiator valve the following aspects must be considered to ensure that the valve performs to its optimum level.

- 1 The valve should be in a position where it is in contact with free air circulation within the area and is not subject to draughts, as this will affect the valve's performance.
- 2 The valve must not be installed in a position where the head is likely to be damaged or where the valve is subject to excessive heat, either at the time of installation or in operating conditions.
- 3 Ensure that the system is clean and free from debris and the installation is in accordance with good plumbing practice.
- 4 An automatic differential bypass valve **MUST** be fitted as part of a TRV installation
- 5 We the manufacturer strongly recommend that the TRV be fitted on the feed side of the radiator. This will help avoid any knocking noise due to differential pressures on the in and the out of the TRV and L/s Valve.

Note: The TRV is only suitable for use as a reverse flow valve when the system differential pressure, across the valve, does not exceed 0.25 bar.