## **INSTALLATION GUIDE MIRUS** This product must be fitted only by a fully qualified installer. 1200mm 900mm DESCRIPTION DESCRIPTION ILLUSTRATION Fixing choose the closer than 50mm appropriate below any overhanging surface fixing for the wall (i.ei shelf) and no material if ower than 100mm required CHANGE HORKEN from the floor. Transfer the bracket PTFE tape drill position Drill the wall and insert wall anchors (1) Electric drill or other suitable fixings). 900mm 1200mm Put the brackets (2) Radiator x1 Masonry drill bit on the wall and screw approplate to the them to the wall fixings anchors (1) with fixing Brackets x4 screws (5) and Adjustable washers (4). spanner Screw the brackets (6) Radiator valve onto the radiator. hex key Wall Anchors Flat head and Insert brackets (6) philips head into the brackets (2) screw drivers and tighten the **Fixing Screws** security screws (3) 1 lock shield Security valve and 1 gate Screws x4 or thermostatic Washers valve Spirit level Measuring tape End plug x1 Air vent x1

## GENERAL RECOMMENDATION

- ■Before fitting the radiator it is necessary to wash out the heating system to remove any existing mud, scale, work residues, traces of flux, oil, etc.
- ■When the system water pH is outside the 5,5-8,5 range and/or when the dissolved is above 0,1mg/litre, it is always needed to protect the heating system components (the radiator is one of these) with a proper chemical treatment compatible with all parts in contact with water (silicon rubber too).
- ■In order to fit the radiator to the wall, it is necessary to choose the proper fixings for the wall material.
- ■If the system water exceeds 50°C, please install a warning mark near the radiator to avoid any accidental scalding.
- ■Clean the radiator surface only with a soft cloth to avoid scratching the finish and do not use chemical againts during cleaning operations. It is prohibited to climb on the radiator.
- ■Maximum working temperature 95°C, maximum working pressure 4 bar.