

### **Fitting Instructions**

1. Mark out the position for secure fixing and prepare floor to accept screws or bolts.
2. Place the spout (1) into the tube.
3. When the spout (1) is sitting in place correctly, insert the grub screw provided in the hole and tighten.
4. Screw the flexible pipes (5) into the port in the water feed block. Do not over tighten.
5. Fit the hose (3) to the outlet, and the handset (2) to the hose ensuring sealing washers (4) are in place.
6. Connect the flexible pipes (5) to supply making sure to use sealing washers (6) and check thoroughly for leaks.
7. Fit the unit to the floor in the appropriate place using the screws (7) provided or installer preferred method.

