Safety

Target group and qualification

The Geberit product is only allowed to be mounted by a trained plumber in accordance with the installation instructions and the safety regulations.

Use

The AquaClean 5000 and AquaClean 5000 plus may only be used as add-on units for WC ceramic appliances with exposed or concealed cisterns.

Do not install the AquaClean 5000 and AquaClean 5000plus in rooms where there is a risk of frost. The minimum ambient temperature is 10 °C.

Explanation of symbols

Symbol	Meaning
	Pay special attention to the activity step.

Contact

For technical information or if you have any questions, please contact the responsible Geberit sales company or visit www.geberit.com.

Technical data

Frequency	50 - 60	Hz
Nominal voltage	230	V AC
Cable length	2	m
Power consumption	850	W
Flow pressure range	1 - 10	bar
Humidity	max. 95	% relative
Net weight	6.3	kg

Installation

Installation difference

These installation instructions show the installation of the AquaClean 5000plus add-on unit. The steps for the AguaClean 5000 add-on unit are not shown but are identical.

AquaClean 5000



AquaClean 5000plus




Installation consists of the following steps:

- Establish the water supply and electrical connection
- Mount add-on unit on WC ceramic appliance
- Connect add-on unit to water supply connection
- Connect add-on unit to electrical connection

The water supply connection of the add-on unit can be established with an exposed or a concealed cistern.

Prerequisites

- Earthed electrical connection provided
- Water supply connection provided
- Dimensions of WC ceramic appliance checked in view of use with AquaClean 5000, AquaClean 5000plus (sample template 998.425.00.0)



Establishing the water supply connection with an exposed cistern

It depends on the type of water supply connection whether or not a water supply connection set is required. The following water supply connection sets are available:


- Water supply connection to the side on the left
 → Included in standard connection set
- Water supply connection to the rear in the centre
 → Water supply connection set art. no.
 115.438.00.1
- Water supply connection to the side on the right
 → Water supply connection set art. no.
 240.396.00.1
- 1 Determine the position of the water supply connection (left side, rear centre, right side)
- 2 Check if the correct water supply connection set is at hand
- Establish the water supply connection according to the installation instructions supplied with the water supply connection set.

Establishing the water supply connection with a concealed cistern

It depends on the type of cistern whether a water supply connection set is required. The following water supply connection sets are available:

- UP300 / UP320 concealed cistern with conduit pipe
- → Water supply connection set art. no. 249.801.00.1
- UP200 concealed cistern element height 82 cm with conduit pipe
 - \rightarrow Water supply connection set art. no. 240.634.00.1
- UP200 concealed cistern element height 98 cm with conduit pipe
 - → Water supply connection set art. no. 240.635.00.1

Check whether the concealed cistern is already equipped with a conduit pipe






Wasseranschluss für Dusch-WC ist vorbereitet. Le fourreau permettant le raccordemer en eau du WCdouche est prémonté. L'allacciamento idrico per un sedile WCdouccetta è già preparato. Wateranasluting voor DoucheWC reed voorbereld. Prepared water connection for Shrower/Disk!

- 2 Check the type of concealed cistern and the element height
- 3 Check if the correct water supply connection set is at hand
- Establish the water supply connection according to the installation instructions supplied with the water supply connection set

Mounting add-on unit to WC ceramic appliance


Tightly screw the filter element onto the underside




2 Check on which side of the WC ceramic appliance the mains connection is located




According to the position, install the mains connection cable on the underside on the left or on the right




Read the serial number from the specification plate and transfer it to the guarantee card (A) or otherwise remove the sticker with the serial number from the packaging of the end-user documentation and attach it to the guarantee card (B)




5 Screw the connection bend onto the valve




6








7 Insert the fastening screws



Put add-on unit with fastening screws onto WC ceramic appliance and slightly tighten wing nuts







GEBERIT


Connecting add-on unit to water supply connection


Depending on the type of water supply connection of the concealed or exposed cistern, the add-on unit is connected differently.

Prerequisites

Water supply connection of concealed or exposed cistern has been established.


1 Close the central water tap






With exposed cisterns, the add-on unit can be connected to the angle stop valve according to the following steps or to the installation instructions supplied with the water supply connection set.


2 Measure the water supply connection




Connect the water supply connection to the connection bend




4 Loosen the connection bend from the add-on unit and turn it downwards





5 Open the central water tap







■GEBERIT











GEBERIT




Prerequisites

Functions are checked at the control panel and control panel is ready for operation.


1 Insert batteries into remote control







2 Cover the window of the user detection with your hand









5 Check the spray intensity by pressing the buttons





7 Start and stop Lady shower by pressing the button



Start-up operation

Making add-on unit ready for operation

Prerequisites

Function checks with the control panel and with the remote control have been completed successfully.

1 Remove the spray shield



2 Clean the add-on unit

Acceptance

Hand add-on unit over to the customer

- 1 Instruct customer about operation
- 2 Explain maintenance notes and cleaning instructions to the customer
- **?** Hand end-user documentation to the customer
 - Fill in the guarantee card together with the customer (end-user documentation) and send it to Geberit