




# Thermostatic Mixer Valve Square and Round Fitting Kit

Ref	Description	Illustration	Qty
A	Chrome Plated Threaded Adaptor		2
B	Wall Plate		2
C	Screw		6
D	Wall Plug		6
E	Olive		2
F	Cover Plate	 or 	2

First check the Thermostatic Mixer Valve (TMV) you are fitting has inlets at approximately 150mm centres and it has  $\frac{3}{4}$ " thread fittings (most have) and they fit the threaded adaptors supplied.

1. Fit the inlet pipes in 15mm copper tube so the outlets are at 150mm centres ensuring the tube protrudes 30mm +/- 2mm from the finished tiled surface. **(fig 1).**

**NOTE:150mm is the standard for Bar Valves  
change pipe centers as required.**

2. Fit the wall plate over the copper tube and mark a suitable place to drill holes. **(fig 2).** Drill the holes and using the wall plugs fit the screws to hold the wall plate lightly in the required position.

3. Fit the olive, it should protrude by at least 4mm from the wallplate.

Tighten up the chrome plated threaded adaptor with a 22mm spanner on to the wall plates so the olive seals on the 15mm tube.

4. Fit the cover plates provided and attach the TMV using the washers. **(fig3a/ 3b)**

