



# Shower Panel Instruction

Product must be installed in compliance with relevant Water Regulations and Byelaws











If you want to higher hot water, please push the button and turn.




**Note:** Installation is the same

## FOR INSTALLATION YOU MAY REQUIRE


 Ø6	 2000MM		
Electric Drill	Tape	Wrenches	Pencil
		 PH ⊕	 PH ⊖
Hammer	Sealing Tape	Screwdriver	Screwdriver

Note: Always check the walls for pipes and wires before drilling.

## Steps:





1. Drill the holes in the wall.
2. Insert the wall plugs inside the holes.
3. Tighten the screws to the wall with wall mounting brackets.



## Note!

Before assembly, flush the water supply pipes thoroughly to remove debris(allow the water to run with the main stopcock open for about 3 mins),otherwise dirt particles might affect thefunction of the shower panel!

## Shower holder installation guide



Note: No harsh abrasive cleaning agents or materials can be used,use a clean damp cloth only.




NOTE: PLEASE CARRY OUT THE FOLLOWING STEPS, IF CLEANING / MAINTENANCE IS REQUIRED


## Thermostatic valve removal and installation

### Remove process


① Take off cap




② Loosen HEX screw off with allen wrench




③ Take off head




④ Take off ring



⑤ Unscrew the brass ring from the valve by tool




⑥ Remove the valve and clean: Run under warm water and use a toothbrush or similar to remove any debris or limescale




### Installation process


① Put the valve back




② Put brass ring on top of valve




③ Put ring in place



④ Press the button on the head and put on the head as below ensuring the screw hole pointing to the front



⑤ Use allen key to fix the HEX screw tightly



⑥ Put on cap

