


Please note: This template is intended for dimensional reference and will not print to scale.




Stage 1. Preparing the Basin Unit

Before you begin you will need to remove the cross bar at the back of the unit (See Fig.1) to allow the basin to fit properly.

1. Using a saw cut the panel down the middle.
2. Pull each half off the unit.

To provide additional support for the worktop in the corner areas of the unit it is recommended that L shaped brackets or batons (not supplied) are screwed directly into the wall behind the unit in the positions demonstrated in Fig.2. Suitable wall plugs and screws will be required depending on the type of wall construction (Brick, plasterboard etc.) The underside of the worktop can be screwed to the batons/brackets once it is cut and in place.



Stage 4. Basin Fitting Instructions

Before you begin it is recommended that you seal all the cut edges of the worktop and fascia with waterproof sealant (not supplied) to avoid water penetration.

1. Apply waterproof sealant (not supplied) to the rim of the basin and the area of the worktop where the two meet.
2. Place the basin (complete with tap and waste fittings) in position on the worktop and apply a firm pressure around all edges of the basin to achieve a good seal.
3. Remove excess sealant.
4. Allow the sealant to set for the recommended duration.

Stage 3. Fascia Cutting Instructions

Before you begin, detach the fascia from the base unit.

1. Measure the worktop thickness.
2. Mark this distance on the Worktop Thickness area of the Fascia Template using the pre printed lines as a guide. Note, if you are using a Roper Rhodes laminate or solid surface worktop the thicknesses of these have been pre marked. Mark a line and lightly score along it then fold along the scored line.
3. Find the centre of the fascia and using masking tape and a pencil mark this position.
4. Lay the cut out Fascia Template on the fascia aligning the centre line with the centre of the fascia marked in the previous step (See Fig.8).
5. Using masking tape mask beneath the template edges on the fascia. Trace around the template outline onto the masking tape.
6. Secure the fascia appropriately on a cutting bench before cutting along the traced outline.
7. Reattach the fascia to the base unit. Proceed to Stage 4. Basin Fitting Instructions.

