


Installation Instructions

30mm Standard Waste Level Access Shower Tray

Parts Supplied

Description		Qty
Shower Tray		1

Parts Required (Fitting Kit)

Description		Qty
Shower Drain Base		1
Shower Drain Socket		1
Shower Drain Reducer		1
Shower Drain Internal Bowl		1
Shower Drain Internal Dome		1
Shower Drain Top		1
Disposable Tiling Aid		1
Shower Drain Finishing Grate		1
Lubricant		1



Materials Required



Description		Qty
Board Fixing Adhesive Bag (5kg)		*
Wood Floor Primer		*
Waterproofing Tape		*
Premix waterproof tape sealing compound (500ml)		*
Waterproofing Internal Corner		*
Protective Gloves		1
Paintbrush		1

*Quantities may vary according to installation.

Before You Start

Parts You May Also Require

Description		Qty
10mm Waterproof Floor Boards		*
Fixing Plate		*

Fixing Plate Screw		*
Sealing & Mounting Adhesive Tube (310ml)		1

Tools required (not supplied)

- Paint Brush (wood floors only)
 - Pencil
 - Hard Point Saw
 - Electric Drill
 - Bucket
 - Solvent Weld Waste Adhesive
 - Timber Batten (approx. 20mm x 50mm)
 - Plywood 18mm (size depends on room)
 - Measuring Jug
 - Notched Adhesive Trowel
 - Tape Measure
 - Straight Edge
 - Circular Saw
 - Breathing Protection
 - Wood Bit
 - Sealant Gun
 - Screwdriver PZ2
 - Jigsaw
 - Eye Protection
-



Before You Start

Important Information

PLEASE READ THESE INSTRUCTIONS THOROUGHLY BEFORE STARTING INSTALLATION. If your product has slightly damaged edges, there is no need to return the product as these can easily be repaired and most minor damage will naturally be covered during installation.

Should you need to patch a repair that won't be naturally covered you should do so in the same way as you would seal a joint with waterproofing tape and tape sealer.

DO NOT PLACE STEP LADDERS OR HEAVY ITEMS ONTO THE SHOWER TRAY OR TRAY EXTENSION PRIOR TO TILING, AS THIS COULD PUNCH A HOLE THROUGH THE SURFACE.

When you are ready to start, make sure that you have the right tools to hand and that the installation area is clean and dry.

When drilling or fixing into walls or floors it is essential that you check for pipes and wires before commencing.

Site Preparation


All floor types need to be clean, dry and dust free.

All floor types need to be as flat and level as possible.

Prior to installation you will need to have access to a waste pipe in the correct position. Please ensure that the waste pipe is accessible and any alterations to the floor are completed prior to installation.

If you are running your pipe work below the floor, the waste pipe must run in the same direction as your floor joists so please check your joists before starting installation.

When you are ready to start, make sure that you have the right tools to hand and that the installation area is clean and dry.




Step 1

Measure the entire floor area and plan the layout on a sheet of paper. Decide if any of the waterproof boards need to be cut and if they do, cut them now using a hard point saw. Lay the entire pack out across the floor area to check the fit.


NOTE: DO NOT WALK ON OR STAND ANYTHING ON THE SHOWER TRAY OR WATERPROOF BOARDS AS THEY CAN EASILY BE DAMAGED AT THIS STAGE.

Carefully remove the waterproof boards and store somewhere safe.



Step 2

Mark the shower tray position onto the floor. Measure the position of the waste hole in the shower tray. Carefully remove the shower tray and store somewhere safe.



Step 3


From the nails or screws holding the existing flooring down, establish where the joists are. Where the edge of the shower tray runs across the joists, the floor cut line will be as marked in Step 2. Where the edge of the shower tray runs in the same direction as the joists, mark the centre line of the first joist outside the shower area as you will

Step 4

Before proceeding, check thoroughly for pipes and wires under the floor. Set the circular saw blade to the depth of the floor boards, it may be necessary to increase the depth slightly if it does not go right through the floor boards. As a safety precaution, we would recommend that the circular saw is plugged into an RCD protected socket. Using the circular saw cut along the lines that you have marked and remove the flooring and all nails or screws.

Step 5

Make sure that the remaining floor boards or sheets in the rest of the room are fully secured down and as level and flat as possible.



Step 6



Note: Make sure all pipes and drainage parts are clean at all times using solvent waste pipe cleaner prior to connection.

40mm Waste Pipe Only.

Solvent weld the shower drain reducer into the shower drain connector.

40mm & 50mm Waste Pipe.

The waste pipe must be properly supported to hold its own weight and that of the shower drain base. Spread solvent weld adhesive around the inside of the drain connector. Push the shower drain base onto the shower drain connector with a twisting action. Spread solvent weld adhesive around the inside of the opposite end of the shower drain connector and then slide onto the waste pipe with a twisting action. Once the solvent weld has set, pour water down the drain to check the waste is not blocked and that there are no leaks. Smear some lubricant around the black rubber seal on the shower drain base.



Step 7

All exposed joists will now need a batten running along the inside of the joist to accommodate the new plywood low level floor. Measure the length of the exposed joist taking into account any obstructions. Cut some timber batten (approx. 20x50mm) to length and screw at approx. 150mm intervals to the inside of all joists 18mm below the top of the joists.

Step 8

Cut some 18mm plywood to fit between the joists on top of the batten fitted in Step 7.




Step 9

Measure the shower drain base position on the floor and mark this onto the relevant piece of plywood. Using a jigsaw cut a hole in the plywood so the shower drain base and shower drain connector will be exposed through the new floor. Please note that the hole should be no bigger than 180x180mm.

Check the position of any pipes or wires and mark these on top of the joist for reference. Lay the plywood into position and pilot drill and countersink making sure you avoid any pipes and wires marked on the joists. Fix the plywood on top of the timber battens with a suitable wood screw at approximately 150mm intervals.


Step 10

If you are left with a gap between the edge of the shower tray and the start of the original flooring, this should be filled with a piece of the flooring that you removed in Step 4 and securely screwed down onto the new plywood.




Step 11

Lay the shower tray into the required position to check the fit of the shower drain base. Once you are happy with the fit, carefully remove the shower tray and store somewhere safe.



Step 12


Put on the protective gloves and wear eye and breathing protection. Paint the entire floor area including the new plywood with the wood floor primer. When you have finished you can remove the protective gloves and eye and breathing protection. Leave to dry for at least 2 hours.



Step 13

Put on the protective gloves and wear eye and breathing protection.

Mix one of the 5kg bags of board fixing adhesive according to the instructions on the bag in a clean bucket which will give the adhesive a stiff consistency. Where the shower tray will sit, spread the board fixing adhesive onto the floor and drag the notched adhesive trowel across the surface. The notched adhesive trowel will make a ribbed pattern which will leave just the right amount of adhesive on the floor.



Step 14


Apply a wavy line of sealant adhesive to the edges of the shower tray where it will touch the walls.

Place the shower tray into position and bed down onto the adhesive. Check that the shower tray is level in both directions along the edge using a suitable level.




Step 15

Put your fingers through the drain hole in the shower tray. Push down on the shower tray and pull the shower drain base upwards until it clicks into place into the drain hole in the shower tray.




Step 16

Ease the shower drain internal bowl into the shower drain base. Ease the shower drain internal dome into the shower drain base.



Step 17


Where the first waterproof board will sit, spread the board fixing adhesive onto the floor and drag the notched adhesive trowel across the surface. The notched adhesive trowel will make a ribbed pattern which will leave just the right amount of adhesive on the floor.



Step 18

Place the first waterproof board into position and bed down onto the adhesive cement. Check that the waterproof board is level in both directions using a suitable level.


The floor is designed to be fitted flat and is fully waterproof, however water will sit on a flat surface. If the floor immediately outside the showering area is likely to get wet, it is advisable to angle the first board slightly so that water will run back towards the drain.



Step 19

Repeat steps 17 and 18 for the remaining waterproof boards, mixing the second bag of board fixing adhesive when required. When you have finished you can remove the protective gloves and eye and breathing protection.


Leave to set for approximately 3 to 4 hours, depending on room temperature.



Step 20


Before proceeding, check thoroughly for pipes and wires under the floor.

Along all joints fit the fixing plates at approximately 300mm centres. Place the centre hole of the fixing plates directly over the joint line and screw to the floor with the fixing plate screws.




Step 21

Place the waterproofing internal corners into position and mark around them with a pencil. Once you have marked they can be removed. This is to show where you need to apply the tape sealer.




Step 22

Put on the protective gloves and wear eye and breathing protection. Using the tape sealer and a paintbrush, apply a thin layer of tape sealer to the internal corners of the shower area, slightly bigger than the pencil line marked in Step 21.




Step 23

Place the waterproofing internal corners into the internal corners of the shower area and push firmly into the tape sealer. Apply a further thin layer of tape sealer over the edges of the waterproofing internal corners.



Step 24

Apply a thin layer of tape sealer to one edge of the floor and adjoining wall approximately 60mm wide on each. Press the waterproofing tape firmly into the tape sealer, folding half up the wall and half on the floor as you go. Repeat this process for the remaining walls. The waterproofing tape should be cut to overlap approximately 20mm onto the waterproofing internal corners.



Step 25

Apply strips of waterproofing tape across all joints and fixing plates using tape sealer and pressing firmly down. When you have finished you can remove the protective gloves and eye and breathing protection.

Leave to set for approximately 3 to 5 hours after which the floor is ready for tiling

Note: Steps 26, 27, 28 & 29 are after the Important Tiling Advice.



Important Tiling Advice


IT IS ESSENTIAL THAT YOU DO NOT USE A READY MIXED TILE ADHESIVE.

S1 FLEXIBLE CEMENT BASED POWDERED ADHESIVE MUST BE USED WITH TILEABLE SHOWER TRAYS.

The shower tray has slopes towards the drain pre-formed into the tray and these must be maintained when tiling as does the slope on the shower tray extension.


If you use tiles that are larger than 100mm it is necessary to cut the tiles along the same lines as are pre-formed into the shower tray to maintain the slope. For best results and ease of installation we would recommend mosaics or tiles of 50mm to 100mm.

Tileable shower trays are perfect for use with electrical under tile heating due to its excellent thermal properties. It is however essential that you check with the manufacturer that their product is entirely suitable for the area that you intend to install it in. If you are installing under tile heating it is essential that you consider any areas that will need products fixed to the floor for example shower screens. Avoid installing under tile heating directly below any fixing point to avoid the risk of damage to the heating mat.



Step 26

Place the disposable tiling aid into the shower drain hole on the shower tray. The tiling aid provides the edge that needs to be tiled up to whilst protecting the drain from debris.




Step 27

After tiling the shower tray the shower drain top can be fitted. Gently place the shower drain top into the shower tray depending on your cutting skill, it may be necessary to file or sandpaper the cut edge to make it completely flat. Measure from the top of the finished tile to the top of the shower drain top.

From the opposite end/bottom of the shower drain top mark the same distance as previously measured.

Using a hard point saw, cut the excess from the bottom of the shower drain top.



Step 28

Place a small blob of tile adhesive in the middle of all four sides of the shower drain hole in the shower tray. Gently ease the shower drain top into position in the shower tray.

Leave to set for approximately 3 to 5 hours




Step 29

Fill the gap between the edges of the shower drain top and the start of the tiles with the same grout used during tiling. Place the shower drain finishing grate into position

Leave to dry for at least 24 hours before using the shower.


9 OPTIONAL PANEL



INSIDE OF SCREEN


FINALLY FOR THE OPTIONAL RETURN GLASS PANEL FIT THE WEDGE SEALS (ITEM 18) INTO THE CORNER PROFILE AS SHOWN ABOVE. PUSH THE SEAL DOWN THE LENGTH OF THE CORNER PROFILE. A WOODEN BLOCK CAN BE USED TO AID FITTING. TRIM OFF ANY SURPLUS SEAL AT EITHER END SO ITS LEVEL WITH THE PROFILE.

10



FINALLY FIT THE WALL PROFILE CAP (ITEM 5). A SMALL BLOB OF SILICONE CAN BE APPLIED TO THE UNDERSIDE OF THE CAP TO HOLD IT IN PLACE IF NECESSARY.

11



EXTERNALLY SILICONE SEAL THE WALL PROFILE WHERE IT MEETS THE WALL AND ALONG THE BOTTOM OF THE GLASS. ALL IN A CONTINUOUS BEAD.

DO NOT SILICONE INSIDE THE ENCLOSURE


ALLOW THE SILICONE AT LEAST 24 HOURS TO FULLY CURE.

AFTERCARE - ENSURE YOU CLEAN YOUR PRODUCT USING A MILD DETERGENT DILUTED IN WATER, REMOVING ANY RESIDUE WITH A SOFT DAMP CLOTH.


MAINTENANCE - ENSURE MOVING PARTS ARE FREE FROM ANY DEBRIS OR SOAP BUILD UP.

TROUBLE SHOOTING GUIDE

1. IS THE TRAY LEVEL (SEE STEP 1).
2. ARE THE WALL PROFILES PLUMB VERTICALLY (SEE STEP 2).
3. DO THE FINISHED TRAY MEASUREMENTS COMPLY WITH THE ADJUSTMENTS LISTED IN THE PRODUCT SPECIFICATION.



WETROOM SCREEN INSTRUCTION



UNPACK THE BOX AND ENSURE ALL COMPONENTS ARE PRESENT.

NO REFUNDS OR REFITTING COST WILL BE GIVEN IF INCOMPLETE OR DAMAGED GOODS ARE FITTED.

THE TOUGHENED SAFETY GLASS SHOULD BE HANDLED WITH CARE AS IMPACTS WILL DAMAGE THE GLASS OR ENCLOSURE.

FIT THE SHOWER TRAY AS PER THE MANUFACTURERS INSTRUCTIONS.

NOTE: IF THE TRAY ISN'T TRUE AND LEVEL, IT MUST BE RECTIFIED BEFORE SILICONING AROUND THE TOP EDGE OF THE TRAY WHERE IT MEETS THE TILES. ALLOW THE SILICONE TO DRY BEFORE FITTING THE ENCLOSURE.

TOOLS REQUIRED


- POWER DRILL - 6mm MASONARY DRILL BIT
- CROSS HEAD SCREW DRIVER - TAPE MEASURE - PENCIL
- SILICONE GUN WITH SANITARY GRADE SEALANT - SPIRIT LEVEL.

FOR A SINGLE SCREEN			
ITEM	DESCRIPTION	Note	QTY
1	WALL PROFILE		1
2	SHOWER WALL GLASS		1
3	PUSH IN 'V' SEAL THICK	FOR 8mm GLASS	1
4	PUSH IN 'V' SEAL THIN	FOR 10mm GLASS	1
5	WALL PROFILE CAP		1
6	TOP BAR WALL SOCKET		1
7	TOP BAR		1
8	GLASS CLAMP		1
9	PVC SADDLE		1
10	GRUB SCREW		4
11	30mm CSK SCREW		1
12	30mm SELF TAPPER SCREW	FOR FIXING TO WALL	3
13	PLASTIC WALL PLUG		4

WALK-IN "T" PIECE SOCKET SET			
ITEM	DESCRIPTION	Note	QTY
14	"T" PIECE SOCKET		1
15	GRUB SCREW		2


OPTIONAL RETURN PANEL			
ITEM	DESCRIPTION	Note	QTY
16	CORNER PROFILE		1
17	RETURN GLASS PANEL		1
18	WEDGE SEALS		2

1




ENSURE THE TRAY IS LEVEL IN ALL PLANES.
IF THE TRAY IS NOT LEVEL IT WILL CAUSE FITTING ISSUES.

2




POSITION THE WALL PROFILES ON THE TRAY IN A SUITABLE POSITION. MAKE SURE THEY'RE TRUE WITH A SPIRIT LEVEL, THEN MARK THROUGH THE FIXING HOLES WITH A PENCIL. REMOVE PROFILES THEN DRILL AND PLUG THE WALL (ITEM 13). NOW FIX THE WALL PROFILE IN PLACE USING ITEM 12.

BEFORE FIXING ENSURE THAT THE CURVED FACE OF THE PROFILE IS FACING OUTWARDS FROM THE ENCLOSURE.




3



OPTIONAL
RUN A SMALL BEAD OF SILICONE DOWN THE INSIDE OF THE WALL PROFILES BEFORE FITTING GLASS. NOW SLIDE THE GLASS PANELS (ITEM 2) INTO THE PROFILES.

4



INSERT PUSH IN 'V' SEALS AS FOLLOWS:


8mm GLASS
ONE THICK SEAL ON THE INSIDE OF THE GLASS PANEL.

10mm GLASS
ONE THIN SEAL ON THE INSIDE OF THE GLASS PANEL.

5a SINGLE SCREEN

ASSEMBLE THE TOP BAR (SUPPLIED WITH SCREEN) AS PER THE DIAGRAM BELOW FOR A SINGLE SCREEN CUTTING BAR "A" TO REQUIRED LENGTH.

ASSEMBLE THE TOP BARS.





5b WALK-IN CONFIGURATION

ASSEMBLE THE TOP BARS (SUPPLIED WITH SCREEN) AS PER THE DIAGRAM ACROSS FOR A WALK-IN CONFIGURATION CUTTING BAR "A" TO REQUIRED LENGTH.


ENSURE BEFORE FIXING THE TOP BAR WALL SOCKET THAT YOU HAVE POSITIONED THE 'T' PIECE SOCKET (ITEM 14) ONTO BAR "A" WITH THE GRUB SCREWS (ITEM 15) FACING UPWARDS.

NOW MEASURE AND CUT BAR "B" TO SUIT.

ASSEMBLE THE TOP BARS.




6



ONCE ASSEMBLED MARK AND DRILL THE TOP BAR WALL SOCKET (ITEM 6). ENSURE THE TOP BAR WALL SOCKET IS LEVEL AND THAT THE GRUB SCREW IS FACING UPWARDS BEFORE FIXING IT TO THE WALL USING ITEMS 11 & 13.

FIT BAR ASSEMBLY.


7 OPTIONAL PANEL



TO FIX THE OPTIONAL GLASS PANEL INTO PLACE, FIRSTLY RUN A SMALL BEAD OF SILICONE DOWN THE INSIDE OF EACH GLASS SLOT ON THE CORNER PROFILE (ITEM 16) STOPPING 5mm SHORT AT EITHER END.

THEN SLOT THE CORNER POST ON TO THE END OF THE SHOWER WALL GLASS (ITEM 2).

8 OPTIONAL PANEL



NOW SLOT THE SMALLER RETURN GLASS PANEL (ITEM 17) TO THE CORNER PROFILE ENSURING CORRECTLY SECURED.