


AREZZO

Walk-In Glass Screen



Fitting Instructions

Please follow them carefully and
leave this manual with end user

Safety Information for User & Installer

Before you begin:

1. **We recommend that this product is installed by a qualified tradesperson,** Victorian Plumbing Ltd. accept no liability for products incorrectly installed or any damage to the floor, walls, plumbing, glass screen, or personal injury during installation.
2. Incorrect installation of the enclosure will invalidate the guarantee.
3. Carefully check the product for transport damage prior to installation.
4. Never install damaged panels as there is a risk of spontaneous glass breakage. The supplied fixings/wall plugs are only for mounting directly on solid walls.
5. It is essential that the solid, masonry/walls be inspected for adequate load-bearing capacity prior to every installation. The supplied fixings/wall plugs are not for use with stud walls such as plaster board, wood, metal or fiber board.
6. Always seek professional advice to confirm wall type and appropriate type of fixing to be used for installation. Always check walls for concealed utility lines (power, gas, and water) prior to drilling the fixing holes.



Special information on handling glass:

1. **Always** protect all glass edges from damage.
2. **Never stand the glass on its corners throughout the installation!** Place the packing material beneath the glass panel; never place the glass on tiles, concrete floors or similarly hard surfaces.
3. It is mandatory to check each glass panel for damage prior to installation. Never install damaged glass panels as this could cause spontaneous glass breakage!
4. If the glass panel is damaged during use, it must be replaced without delay. **(Failure could cause a risk of spontaneous glass breakage!)**


Prevent damage to glass or operation of the product:

1. Ensure that no objects obstruct the glass panel.
2. Avoid hitting the panels with hard objects or tools during assembly. Damaged panels must be replaced as failures may cause latent glass breakage.
3. Do not use panels or handles to hang or support items such as drying towels or clothes.
















Diagram:



| SIZE | A |
|------|-----------|
| 700 | 680-690 |
| 800 | 780-790 |
| 900 | 880-890 |
| 1000 | 980-990 |
| 1100 | 1080-1090 |
| 1200 | 1180-1190 |
| 1300 | 1280-1290 |
| 1400 | 1380-1390 |



Items included:


| No. | Description | Picture | Qty |
|-----|--------------------|---|-----|
| 1 | Top Cover Cap |  | 2 |
| 2 | Small Cover Cap |  | 2 |
| 3 | Profile |  | 2 |
| 4 | Rawl Plug |  | 10 |
| 5 | Glass Panel |  | 2 |
| 6 | ST3.9X35 Screw |  | 8 |
| 7 | Arm Bar |  | 2 |
| 8 | ST3.9X40 Screw |  | 2 |
| 9 | Panel Holder |  | 2 |
| 10 | Arm Bracket |  | 2 |
| 11 | Screen Fittings |  | 6 |
| 12 | ST3.5X9.5 Screw |  | 6 |
| 13 | T-Junction Bracket |  | 1 |
| 14 | Allen Key | 2.5mm 3mm   a b | 2 |

Tools Required (Not Included):

Ensure the appropriate PPE is used during installation



Pencil



Tape Measure



Drill



Screw Driver




Spirit Level




Silicone

Diagram & Fitting for Return Screen:




| No. | Description | Picture | Qty |
|------|---------------------|---------|-----|
| Sp01 | Top Cover Cap (L/R) | | 2 |
| Sp02 | Return Screen | | 1 |

| SIZE | A | B |
|------|-----------|-----|
| 700 | 680-690 | 215 |
| 800 | 780-790 | |
| 900 | 880-890 | |
| 1000 | 980-990 | |
| 1100 | 1080-1090 | |
| 1200 | 1180-1190 | |
| 1300 | 1280-1290 | |
| 1400 | 1380-1390 | |




Step 1:

- Confirm the position of the 'Profiles', mark the fixing points to the wall ready for drilling. Ensure the markings are level using a spirit level.



Step 2:












- Place the 'Profile' to one side. Using an appropriate sized drill bit, carefully drill the holes in the wall. Ensure that there are no hidden pipes/cables behind the wall markings. Insert the 'Rawl Plugs' provided into the drilled holes.



- Place the 'Profile' over the 'Rawl Plugs' and secure into place using the 'Screws' provided. Ensure the 'Profile' is level using a spirit level.










Step 3:

- Carefully insert the 'Glass Panels' into the 'Profiles' on the wall. Ensure the Panels are fully inserted into the Profiles.
- Insert the first 'Arm Bar' into the 'T-Junction Bracket' then attach the 'Panel Holder' and the 'Arm Bracket' to both ends of the arm bar. Repeat this task for the other arm.
- Mount the arms to the 'Glass Panels' then mark the position on the wall for the 'Arm Bracket'. Using an appropriate sized drill bit, carefully drill the holes in the wall then insert the 'Rawl Plugs'. Remove the fixing plate from the 'Arm Bracket' and attach the plate to the wall using the 'Screws' provided.




Step 4:

- Mount the 'Panel Holders' onto the top of the glass panels and secure into place using the 'Allen Key' provided, place the cover caps over the back of the 'Panel Holders'.
- Mount the 'Arm Bracket' over the fixing plate on the wall. Tighten all the top screws with the 'Allen Keys' provided to secure the arms to the screens.
- Secure the 'Glass Panels' to the wall by using an appropriate sized drill bit to carefully drill the holes into the profiles and panel seals (inside facing). Insert the 'Screen Fittings' into the drilled holes on the profiles and secure into place using the 'Screws' provided.
- Insert the 'Small Cover Cap' within the top of the profiles, then insert the 'Top Cover Cap' over the top of the profile. Ensure that both caps are fully inserted into place.



Step 5:

- Pipe a fine bead of good quality silicone sealant along the upright outer edge of the profile and bottom of the panel (including where the screen and the profile meet.)
- Wipe away any excess silicone with a damp cloth and allow 24 hours for the sealant to fully dry.







Attention:
Do not use your shower enclosure within 24 hours of assembly.



Return Screen Installation:

- Pipe a fine bead of good quality silicone sealant within the profile of the 'Return Screen', then carefully insert the 'Return Screen' along the edge of the front glass panel. Insert the 'Top Cover Cap (L/R)' over the top profiles of the glass panel and return panel.
- Wipe away any excess silicone with a damp cloth and allow 24 hours for the sealant to fully dry.



Attention:
Do not use your shower enclosure within 24 hours of assembly.



Cleaning:

Do not use steam cleaners, caustic or aggressive cleaning and scouring agents, cleaners that corrode plastics, or solvents containing acetone, turpentine or neat bleach.

- Do not use any cleaning agents, which may corrode aluminium or light alloys.
- To prevent damage to glass coating system, do not use glass cleaning pastes and micro-fibre cloths.
- In order to prevent the build-up of lime scale, remove any remaining drops of water after showering using a squeegee, soft cloth without any cleaning agent.
- After use, carefully rinse off all residue such as; liquid soaps, shampoos, shower gels or similar cosmetic product with water to avoid deposits.

Important: Never apply the cleaning agent for longer than necessary. After cleaning, check all the moving elements are sufficiently greased, re-grease if necessary.

Service/Repair and Inspection for Safety:

After cleaning, check all the moving elements are sufficiently greased, re-grease if necessary, only use acid-free grease.

Recycling and Disposal:

Please recycle the packaging in accordance with your local government regulations on waste handling, and follow the same advice at the end of the products life.

Notes:

www.victorianplumbing.co.uk