

# Assembly instructions


**We highly recommend that this product is installed by a qualified professional. Installation must comply with any water regulations or any particular regulations as specified by your local water company.**

## Overflow pipe assembly

1. Identify all components are present prior to installation.
2. Remove screw (2) from flange (3), then remove the flange from the waste body (6).
3. Secure the waste body (6) against the underneath of the bath with the sealing washer (5) in position. Use the flange (3) with the rubber washer (4) between the flange & the bath, securing the assembly with screw (2).
4. It is recommended that silicon sealant be applied to all sealing faces of the washer (4).
5. Tighten screw (2). Do Not over tighten.
6. Use the conical washer (7) & nut (8), in the order shown, to hold the tube (9) into the waste body (6).
7. Use the same process to assemble the overflow elbow (10) to the tube (9).
8. Secure the overflow elbow (10) to the bath using the sealing washer (11) & the overflow washer (12), positioned either side of the bath surface. Then place the overflow (13) on top of the overflow washer (12) & secure the assembly using screws (14).
9. It is recommended that silicon sealant be applied to both sealing faces of washer (12).
10. Tighten screw (14). (DO NOT OVER TIGHTEN).
11. The overflow pipe can be cut to size if needed.
12. Check all joints & connections for leaks.

### Components

1. Plug
2. Screw
3. Flange
4. Rubber washer
5. Sealing washer
6. Waste body
7. Conical washer
8. Nut
9. Chrome tube (over sizes)
10. Overflow elbow
11. Overflow seal washer
12. Washer
13. Overflow
14. Fixing screw




**NOTE: Please be advised that no abrasive agents or materials or harsh chemicals can be used for cleaning this product, otherwise warranty will be void, Please clean with warm soapy water, use soft cloth only.**

## Bath waste assembly

1. Connect trap to bath waste ensuring rubber washer is in place.
2. Cut outlet tube to required length (for wall or floor outlet).
3. Slide free nut onto outlet tube, flanged side first.
4. Place rubber seal onto outlet pipe.
5. Tighten free nut onto trap.
6. Fit flange over short end of outlet tube.
7. Attach multi-fit connector to short end of outlet tube.
8. Check for leaks.
9. Push flange against floor or wall.

### **IMPORTANT NOTE.**

Always release the captive nut before attempting to align the outlet tube. Failure to do so will result in damage to the sealing components.



**victorian plumbing.co.uk**

