

ERCE - CORNER ENTRY ENCLOSURE (Note this is a 2 person assembly)

1. Fit the shower tray ensuring it is level across all areas and apply silicone sealant to the edges of the tray after tiling (Fig 1).
2. Take the wall channels (A) and position them 10mm from the front edge of the tray making sure they are vertical and plumb. Mark the fixing positions and drill for the wall plugs (x3) with an appropriate drill bit. Fit the wall plugs. Take care to avoid any hidden pipes or electrical cables (Fig 2).
3. Assemble the top and bottom rails (I) using corner bracket (J). Fix using the 10mm screws supplied. Note! It's important that the correct profiles are used at the top and bottom of the enclosure. See diagram on opposite page.
4. Fix the vertical profile (B) to the bottom rail assembly and screw through the vertical profile using the 30mm Screws as in Fig 4. (x2)
5. Fix the vertical profile at the opposite end again using the 30mm screws (x2). Repeat this for fixing the top rail assembly as in Fig 5.

Note! It is recommended that 2 people carry out this operation.

6. Slide the wall channels onto either side of the assembled frame, carefully lift the frame into position and fix to the wall using the 30mm screws. Once aligned, drill x2 holes 150mm from the top & bottom on the inside of the enclosure with a 3.2mm drill bit, through the wall channel and frame (Fig 6) Secure by using the 10mm screws making sure the support cups are used.
7. Fit the glass side panel (D) into the vertical profile, then fit the fixed panel seal (C) on the inside between the glass and vertical profile as in Fig 7/8.
8. Fix the glass clamps (x2) into the pre-drilled holes in the top and bottom rail with the 10mm screws (Fig 9). See diagram on opposite page.
9. Fit the double wheels into the pre-drilled holes (x2) in the glass door (G), by tightening the pre-inserted screw. (Fig 10)
10. Fit the quick release wheels (x2) to the opposite end, again by tightening the pre-inserted screws. (Fig 11)

Note! The doors need to be made up as a pair (LH & RH)

11. Hang the doors onto the top rail (Double wheels to the top) making sure that the wheels are located in the channel. Then from the outside push down on the spring loaded wheels and clip into position. (Fig 12)

Adjust using the adjustment screws as required.

12. Fit the handles using the 20mm screws supplied.
 13. Measure and trim to length the magnetic door seals (H) and fit to the vertical edges of the doors (Fig 13).
 - Measure and trim to length the vertical door seal (F) and fixed panel seal (E).
 14. Apply silicone down the vertical edges of the wall channel, fixed glass panel and the bottom edge of the fixed glass panel (Fig 14/15).
- Seal (K) is provided for the top & bottom edges of the fixed glass panel if preferred.

DO NOT SEAL THE ENCLOSURE ON THE INSIDE OF THE TRAY!

Fig 1



Fig 2



Fig 3



Fig 4




Fig 5




Fig 6



Fig 7



Fig 8



Fig 9



Fig 10



Fig 11



Fig 12



Fig 13




Fig 14















Fig 15



ERCE CORNER ENTRY FITTING INSTRUCTION



ENCLOSURE PARTS LIST		
A	WALL CHANNEL	2
B	VERTICAL PROFILE	2
C	VERTICAL WEDGE SEAL	2
D	FIXED GLASS PANEL	2
E	VERTICAL PANEL SEAL	2
F	VERTICAL DOOR SEAL	2
G	GLASS DOOR	2
H	MAGNETIC DOOR STRIP	2
I	TOP & BOTTOM RAILS	4
J	RAIL CORNER BRACKET	2
K	BOTTOM GLASS SEAL	2

FITTINGS LIST		
	10mm SCREWS	20
	20mm SCREWS	4
	30mm SCREWS	14
	WALL PLUGS	6
	GLASS CLAMP	4
	SCREW CUPS	10
	COVER CAPS	10
	GLASS SEAL (T)	2
	WHEEL STOPS	8
	DOUBLE WHEEL	4
	QUICK RELEASE WHEEL	4
	HANDLE	4

