
Victorian plumbing.co.uk

Tall Storage Unit with Leg Set



Fitting Instructions

Please follow them carefully and leave this manual with end user

Before you begin:


- 1. We recommend that this product is installed by a qualified tradesperson, Victorian Plumbing Ltd. accept no liability for products incorrectly installed or any damage to the floor, walls, plumbing, tall units or personal injury during installation.
- Check the chosen wall space for any pipes/cables prior to drilling 2.
- 3 We recommend that Tall Units must be fastened to a load bearing wall. Check the type of wall you are fixing into and use suitable fixings.
- 4. Observe all local plumbing and building codes & regulations.
- Unpack the product then read these instructions before proceeding. Inspect the product 5. for damage. If any damage is found, contact our Customer Relations team.

Items Included:

No.	Description	Picture	Qty
А	M4x14mm Short Screw	-autitute (b	16
В	Leg Set		4
с	Ø8x35mm Rawl Plug		1
D	M5x50 Screw		1
E	Washer & Cover Cap	0 +	1
F	Shelf Support	ØS	8
G	Shelf		2
н	Shelf Plugs	S	32

Tools Required (Not Included):

Ensure the appropriate PPE is used during installation




Installation

Diagrams are for illustration purposes only. Your Tall Unit may superficially differ from these drawings however the installation guide steps still apply.

Step 1:

- On the underside of the unit, mount the leg sets (B) to the unit using the screws (A) provided.
- Place the unit up against your chosen wall, then mark the positions of the pre-drilled hole at the back plinth of the unit.




Step 2:

- Drill a hole in the wall using the appropriate sized drill bit, then insert the rawl plug (C).
- Place the unit up against your chosen wall.
 Secure the unit to the wall using the screw
 (D) and washer (E) provided. insert the cover cap over the screw.

Step 3:


 Insert the supplied shelf supports (F) into the pre-drilled holes at the desired height, then place the shelves (G) on-top of the supports. Check that the shelves are level. Plug the rest of the holes using the shelf plugs (H).



Door Drilling & Hinge Adjustment

- Some doors are supplied non-drilled for the handles/knobs so that the end user can create
 the exact look that they want to achieve. Select your desired handle position. Always measure
 twice before drilling to make sure that the handles will be in the correct position. Check that
 the hinges and internal components are not in the way of where the handles will be drilled.
- Using an appropriately sized drill bit, drill through the back of the door into a scrap piece of wood to help prevent splitting.

NOTE: DRILLED DOORS CANNOT BE RETURNED.



Door Hinges:

These should be wiped out with a damp soapy cloth and wiped dry with a soft cloth as necessary. The hinges are lubricated and should not be cleaned with a degreasing agent as this will affect the action of the moving parts. Never lean on partially or fully opened doors in order to gain access to the units. The hinges are specified to adequately support the weight of the door, plus small additional weights such as wire accessories. It is advised that once the bathroom has been installed you should check every six months that all screws on the hinges are tight.

Please Note: Unit is water resistant, but not waterproof. All spillages and splashes should be wiped dry, failure to do so may shorten the life expectancy of the product and invalidate any guarantees.

Recycling and Disposal:

Please recycle the packaging in accordance with your local government regulations on waste handling and follow the same advice at the end of the products life.

www.victorianplumbing.co.uk

victorian

plumbing could