

Corner Panel

Instruction Manual

CGM




PO Box 125, Whitworth Avenue,
Aycliffe Business Park,
Co Durham DL5 6WX

12

EN 14428:2008+A1

To obtain a copy of the Declaration of Performance for this product, please go to: www.ce-dop.com, contact us on +44 (0) 1325 328034, or write to us at the above address, quoting the product reference number where possible.



IMPORTANT INFORMATION

- Toughened glass is completely safe for use in our shower enclosures and bath screens; providing our products are installed according to our guidelines.
- It is important to note that the glass must not be mounted or 'pinched' in such a way that would cause a stress point to develop in the glass. In addition, it must not be subject to any sharp impact or severe temperature fluctuation which may also cause a stress point to develop in the glass.
- Toughened glass is physically and thermally significantly stronger than standard glass. During the toughening process the stresses contained within any glass are balanced so if in the unlikely event situation any of the above occurs and the glass breaks, the glass will shatter safely into small thumbnail sized blunt fragments.

PRE-INSTALLATION CHECKS

1. Check you have the correct product. Please look at the labels on the side of the product packaging.
2. Check all the product components are in the box and the fixing kits.
3. Unpack your product and handle it with care.
4. Please check the product for defects or damage, once the installation has commenced we cannot accept responsibility for any defects or damage.
5. Please take time to read these instructions prior to installing your product.
6. Before you commence any drilling check there are no hidden electrical cables and/or water pipes.
7. No attempt should be made to re-work the toughened safety glass.
8. The installation of the product should be performed by two persons.
9. It is strongly recommended that the walls the product is going to be installed on are vertical.
10. It is strongly recommended the product is fitted on a tiled surface or similar waterproof surface.
11. It is strongly recommended the walls are tiled and grouted before the product is installed.
12. If the walls and/or the tray are not level you will not achieve maximum adjustment of the product.
13. Pictures used are for illustration purposes only, product designs may alter slightly as a result of continuing product development.
14. We do not stipulate where the European Standard Kite Mark should be positioned on the glass when being factory assembled.
15. Please note that some natural misting may occur when you remove this product from its packaging, due to the addition of the glass protection pre-coating. If this does occur this can easily be removed with a soft, dry cloth.

Component Check List: Supplied

Description	Quantity
Corner Post	1
Side Panel	1

Equipment Check List: Not Supplied

Description
Electric / Battery Drill
6mm Masonry Drill Bit
4.5mm Metal Drill Bit (if required)
Sealant Gun
Bathroom Sealant
Screwdriver
Spirit Level
Tape Measure
Pencil
Wall Plugs (plasterboard)

Fixing Kit Components


Description	Quantity
9mm Screws	6
Coloured Caps and Bases	6
Branding Badge (where applicable)	1

CONSUMER GUARANTEE






Please make sure the purchaser/end user completes and returns the guarantee card which is enclosed with this product. Failure to validate the Guarantee will mean only the 1 Year Statutory Guarantee will apply.

Step 1 - Tray and Wall Profiles

① ②








③



1. Ensure the tray is completely level, check for any movement by standing in it. Fill the tray with water to check all plumbing for leaks.
 - **Note: Please ensure that the tray is installed as per the manufacturers instructions.**
2. The tray should be fully sealed along the tiled walls prior to installation with a Bathroom Sealant (not supplied). Prior to commencing installation of the Enclosure and once the sealant has set, spray the shower handset around all joints to check for leaks.

For the following steps please refer to your Door Instruction Manual.
3. Using the Wall Profiles from your Door fit both Wall Profiles 10 to 15mm from the front outside edge of the tray. The lip section of the Wall Profiles should face inwards. Make sure both Wall Profiles are completely vertical using a Spirit Level. Mark the slots with a pencil where the Wall Profiles are to be positioned.
 - **Note: Prior to fitting both Wall Profiles 10 to 15mm from the front edge of the tray, you must ensure you are within the minimum and maximum frame adjustment.**
4. Drill the wall with a 6mm Masonry Drill Bit (not supplied) where the Wall Profiles are to be positioned. Fit the Wall Plugs supplied (if going into brick or block wall). If going into plasterboard you will need to buy appropriate wall fixings. Wipe clear all debris from the tray before referring to the next stage.
5. Where both Wall Profiles are to be positioned on the tray, place a bead of sealant (not supplied) the width of the Wall Profile along the tiled wall. Screw the Wall Profiles to the walls with the 40mm screws (supplied). Do not overtighten the screws into the Wall Profiles as this will misshape the Wall Profile. Ensure the Wall Profiles stay completely vertical throughout this procedure using a Spirit Level.
 - **Note: No sealant allowed between the Wall Profiles and the tiled walls vertically prior to screw fixing.**
6. Seal the gap between the tray and Wall Profiles with Bathroom Sealant (not supplied)
 - **Note: Failure to carry out this procedure correctly can result in serious water damage and is not covered by the Guarantee.**


Step 2 - Fitting Panel



1. On the side of the tray that the Panel is to be placed, slide the Panel into the Wall Profile and push it completely into the Wall Profile.
2. Slide the Corner Post completely onto the opposite end of the Panel following the arrow. Ensure that the long edge of the Corner Post is located onto the Side Panel.
3. Adjust the Corner Post and Panel so that the Corner Post is aligned with the other Wall Profile. To achieve this slightly ease the Side Panel away from the Wall Profile in which it is sitting. For further adjustment ease the Corner Post away from the Side Panel.
4. The Wall Profile and Corner Post holding the Side Panel must overlap the Side Panel by at least 5mm. Inside the enclosure drill three holes into the Wall Profile and Corner Post. The three holes should be drilled approximately 100mm from top and bottom and one in the centre. During this procedure ensure the Corner Post remains aligned with the other Wall Profile.
 - **Note: Use a Spirit Level to keep the Side Panel and Corner Post completely vertical in this procedure.**
5. Fix the 9mm screws into the Base Caps then screw fix into the holes previously drilled. Press fit the Cover Caps into place over the Base Caps once the screws are fully tightened.
6. **Pivot Door** - If you are fitting a Pivot Door, follow Step 2a Installation Procedure A from Stage 1 onward of your Pivot Door Instruction Manual. (On Stage 4 of Step 2a of the Pivot Door Instruction Manual, one Wall Profile will now be replaced by a Corner Post).
Bi-Fold Door - If you are fitting a Bi-Fold Door, follow Step 2a Installation Procedure A from Stage 1 onward of your Bi-Fold Door Instruction Manual. (On Stage 3 of Step 2a of the Bi-Fold Door Instruction Manual, one Wall Profile will now be replaced by a Corner Post).
Hinged Door - If you are fitting a Hinged Door, follow Step 2a Installation Procedure A from Stage 1 onward of your Hinged Door Instruction Manual. (On Stage 3 of Step 2a of the Hinged Door Instruction Manual, one Wall Profile will now be replaced by a Corner Post).
Sliding Door - If you are fitting a Sliding Door, follow Step 2a Installation Procedure A from Stage 1 onward of your Sliding Door Instruction Manual. (On Stage 3 of Step 2a of the Sliding Door Instruction Manual, one Wall Profile will now be replaced by a Corner Post).
7. Ensure the Branding Badge is placed prominently on a none moving aluminium part.

Spare Parts

If you need to replace any damaged parts please see illustration below for parts list then call Customer Relations on 01325 328033



Part No.	Description	Q'ty	Part No.	Description	Q'ty	Part No.	Description	Q'ty
1	Panel	1	11			21		
2	Corner Post	1	12			22		
3			13			23		
4			14			24		
5			15			25		
6			16					
7			17					
8			18					
9			19					
10			20					

TROUBLE SHOOTING GUIDE

Problem	Solution
Leaking	<ol style="list-style-type: none">1. Check that the inside gap between the Tray and Wall profiles has been sealed correctly.2. Ensure the tray is sealed along the tiled walls prior to installation.3. If the inside joint between the enclosure and the tray top is sealed, this will cause leakage - sealant must be removed.4. Ensure the wall profiles on the tiled walls are sealed both vertically inside and outside.5. Ensure the joint between the enclosure and tray top is sealed. <p>Important: This enclosure should be water tested conforming to BS EN 14428</p>
Enclosure Alignment on the Tray	<ol style="list-style-type: none">1. Is the side panel fitted onto a tiled wall?2. Are the Wall Profiles fitted 10 to 15mm from the front outside edge of the tray?3. Are the Wall Profiles and Corner Post completely vertical?4. Ensure the long edge of the Corner Post is located on the Side Panel correctly.

Some important information to help you Maintain your product.

The following information is all you need to keep your product looking new.

Clean your product using a mild detergent diluted in water and then polished off using a soft cloth. If you live in a hard water area, periodically clean your product using a 50/50 solution of white vinegar and water. The solution should be left on the enclosure for approximately 5 minutes then rinsed off using warm water. This method of cleaning should remove lime scale residue.

Simple Maintenance

Our products are generally maintenance free, however it may be necessary to lubricate wheel assemblies and other moving parts from time to time.

It is strongly recommended that a quality silicone spray is used.

A list of Don't's:

1. Don't use acidic based products which are unsuitable for cleaning enamel surfaces.
2. Don't use abrasive cleaners or cleaners using bleach or solvents, these products will adversely affect the finish of the aluminium profiles.
3. Don't use scouring pads, powder or any sharp instruments when cleaning the enclosure.

Should you experience any problems during installation please refer to the Trouble Shooting Guide or contact Customer Relations on:

+44 (0) 1325 328033

To enable customer relations to provide you with an excellent level of service it is important that you quote your product Code and Reference Number - these can be found on the Guarantee card.