

INSTALLATION INSTRUCTIONS

simpsons 

IMPORTANT - Please read before installation

Please read these instructions carefully before starting installation and keep in a safe place for future reference.

Check the contents of the pack carefully before installation. Simpsons will not be held responsible for any de-fit / re-fit costs where faulty product has been fitted.

If any fault is found with materials or workmanship, it must be reported immediately to the manufacturer. Remedial action will be taken, based on information received, on condition that:


1. Full details are supplied to the manufacturer;
2. The enclosure has not been modified or tampered with;
3. The manufacturer is informed of any damage/shortages prior to installation.

We do not accept responsibility for any problems that may occur through incorrect installation.

The success of the installation and operation of any shower enclosure is, of course, dependant on the squareness, alignment and construction of the walls to which fixing is to be carried out.

VERY IMPORTANT

You must complete all tiling and grouting, and the bath **MUST** be level and fully sealed to the tiles before installation. If you do not fit the enclosure onto a tiled surface, or seal the tiles to the bath before installation, water may soak into the wall behind the wall profiles.



INSTALLATION - Advice and safety

The installation instructions are based on typical use and conditions.

The shower screen is designed to open outwards only.

These hints have been prepared for your guidance, you must exercise due care at all times.

For Health and Safety 2 people must carry out the installation of this enclosure.

Handle glass with care. Although the glass supplied is toughened safety glass (EN12150), impacts can damage both the glass and the frame.

Warning!

Please check for any hidden pipes or cables before drilling holes in the wall.

When using power tools always follow the manufacturers user instructions.

If the Framework is sealed to the bath on the inside, any water that may get into the framework will not be able to drain back into the bath, this may cause the enclosure to leak.

Leave the silicone sealant to dry for 24 hours before using the enclosure.

CARE AND CLEANING

Do not use solvents or abrasive material or chemicals to clean the enclosure.


Only clean using soapy water and a soft cloth, rinse thoroughly afterwards.

INSTALLATION - Left and Right hand

This product is reversible for left or right hand opening.






Please follow the diagram, and detailed below for your choice of installation.

- Left entry, The "up" arrow on the glass should be in red, and be on the outside of the enclosure.
- Right entry, The "up" arrow on the glass should be in blue, and be on the outside of the enclosure.



CONTENTS



A		ST4x35mm B *Screw x 5
B		Wall Plug x 5
C		M4 *12mm Screw x 3
D		M8*8mm Grub Screw x1
E		M5*10mm Grub Screw x2

F		M5*5mm Grub Screw x2
G		Allen Key 2.5mm x 1
H		Allen Key 4mm x 1
I		Glass Clamp x1
J		Support Bar x1


K		Wall Bracket x1
L		Hinge x 2
M		Waterproof Strip x 1
N		Plastic Seal Strip x 1

Tools and equipment needed

Drill, 6mm Masonry drill bit, 3.2mm General drill bit, Philips screwdriver, Spirit level, Pencil, Scissors, Silicone sealant.

Step 1 - FITTING AND POSITIONING WALL CHANNEL

⚠ REFER TO PAGE ONE FOR YOUR CHOICE OF INSTALLATION - LEFT OR RIGHT!




Remove wall channel from the side panel frame. Place wall channel in position on the Bath (20~22mm in from the edge of the bath), use a spirit level to ensure that it is vertical and mark all 3 fixing holes onto the wall.

Drill holes in the positions marked using a 6mm masonry drill bit. Insert wall plugs (B) into all of the holes (beyond the thickness of the tile).


Fix the wall channel to the wall using 3 screws (A).

Note: Inject silicone sealant into the holes before inserting the screws to seal the holes.



Step 2

Push the side panel on to the wall channel.




Step 3

Place part (k) in position (5mm above the side panel in vertical; 75mm from the side panel in horizontal.)







Use a spirit level to check the level.

Mark the hole positions on to the wall.


Drill holes in the positions marked using a 6mm masonry drill bit. Insert wall plugs (B) into the two holes. (beyond the thickness of the tile).





Step 4 - FITTING THE BRACING BAR



Step 5 - HINGE ASSEMBLY




Fix Hinges to side panel .
Support door and fix hinges to door . Do not fully tighten.
Check that the door closes and that the top is aligned with the side panels . Fully tighten screws.




Step 6

Depending on whether you have a right hand or left hand hinged door please select the correct diagram shown below for the fitting of Bottom Waterproof Strip.




Step 7 - FITTING SEALS





Step 8

Once you have checked that the door opens and closes correctly fix the side panel to the wall channels.

 **For installation please close the door when drilling to ensure best location.**

From inside, drill 3 holes through each wall channel/side frame using a 3.2mm drill bit. Fix using screws (C)



Step 9

