

Installation Instructions for Shower Seat Model C&D

A fully qualified and competent person should install this product.

Tools Required (not supplied)

Pencil; Tape measure; Screwdriver appropriate to fixings; Spirit level; Drill; Masonry drill bit appropriate to fixings, Ceramic drill bit (optional) appropriate to fixings.

Home Safety Advice

- It is recommended that two people fit this product to ensure that it is fitted safely.
- Always take care when using power tools, particularly in the bathroom.
- Always check for hidden cables and pipework before drilling and take extreme care if there is any water in the working area.
- It is advisable to use a residual current circuit breaker (RCCB).
- Always wear suitable eye protection when drilling.
- If the product is to be fitted on a ceramic tiled wall, a ceramic drill bit should be used.
- Always ensure that the drill hole passes through the central tiled area rather than through the grouted area. To prevent damage to the tile, mask the area around the hole with tape before drilling.
- Do not strike the product with hard or sharp objects.
- Warning! This product has been designed as a seat only and should not be used for any other purposes.

Maximum Weight – 160 kg evenly distributed about the seat.

Product Location

Shower seats are only as strong as the wall to which they are fixed and the fixings that are used. For different wall types you will need to ensure that you are using the correct type of fixing for the material of the wall. The addition of backboards on the outside of the wall or appropriate strengthening of internal structures may be required to provide adequate wall strength.

Product Care

To retain the best quality finish, clean product regularly with a soft damp cloth. Do not use abrasive or chemical cleaners as these will damage the product. Dry the shower seat after use.

Note: If the wall is made of lightweight thermal blocks, aerated hollow brickwork, or prefabricated partitions, even the most appropriate fixings may not be able to withstand the loads which can be suddenly applied to shower seats.

Recycling and disposal

Please recycle the packaging in accordance with your local government regulations on waste handling and follow the same advice at the end of the products' life.

For more Information

Visit: victorianplumbing.co.uk

Before installing, please read the instructions carefully in order to install and use this product safely.

Note:
The structure and installation method for Model C is the same as for Model D.




MODEL C



MODEL D

Spare parts List:



- 1) Main body for shower seat
- 2) 8x60mm rawl plug
- 3) 5x60mm expand screw
- 4) Fixing bracket
- 5) 5x8mm hex socket Grub Screw

Installing steps:

- A) Place the fixing bracket on the wall in the desired location and using a spirit level ensure it is level.
- B) Using a pencil mark the fixing holes ready for drilling.
- C) Drill the 5 holes using an 8mm masonry drill bit then insert the raw plugs.
- D) Proceed to screw the wall bracket securely to the wall using the screws provided.
- E) While holding the main body of the shower seat carefully locate the top edge of the seat bracket onto the wall bracket, then in a downward motion locate the seat firmly on to the wall bracket.
- F) Finally using a Hex Socket screw down the two grub screws.



Dimensional drawing:



Packing List:

Serial No.	Name of components	Quantity	Remark
01	Main body for shower seat	1	
02	8*60mm rawlplug	5	
03	5*60mm expand screw	5	
04	Fixing board	1	
05	Hex socket spanner	1	
06	Instructions	1	

Important:

1. Safe Working Load **160** kilogram.
2. If the Supplied Screws/Raw plugs are not Suitable for Installation you must select appropriate ones.